

NINJA FROSTVAULTTM GO

TIPS AND TRICKS ON HOW TO LUBRICATE YOUR ZIPPER

STEP 1: CLEAN ZIPPER



STEP 2: DOT LUBRICANT



STEP 3: OPEN AND CLOSE ZIPPER



STEP 4: REPEAT AFTER STORAGE

⚠ NOTICE: Excessive lubricant may stain.

MAINTAINING YOUR ZIPPER

The zipper is leakproof so it may need a little extra force to pull.

Clean your zipper with warm water after each use to clear dirt and debris. Then, add 4-5 dots of lubricant along the zipper teeth. Open and close the zipper 4 times to evenly distribute lubricant.

We recommend repeating this process if your cooler has been stored for a long period of time. Never force your zipper if it feels stuck.

