



NINJA

FROST VAULT™

30-QT COOLER

WITH

ALL-TERRAIN
WHEELS

GET TO KNOW YOUR COOLER

TELESCOPING HANDLE

Reinforced, extra-strong handle is designed for easy hauling and ultimate comfort.

LOCKABLE LID & DRAWER

Easy-close, one-handed latch seals lid securely.

ALL-TERRAIN WHEELS

Puncture resistant and ready for any adventure.

NINJA FROSTVAULT™ DRY ZONE

Easy access to your essentials, keeping them cold, dry, and separate from the main cooler full of ice.

DRAIN PLUG

Mess-free, easy drainage.



THICK INSULATION

Inner-wall insulation delivers longer-lasting ice retention.

DRIER. SAFER. COLDER. EASIER.

Ninja FrostVault™ Technology delivers food-safe fridge temps for days under 40°F. Keeps your food cold, dry, and separate from the main cooler full of ice vs. traditional coolers with wire baskets that can quickly reach unsafe food temps (over 60°F).

EXCLUSIVE
NINJA
FROSTVAULT™
DRY ZONE



VS



THEIR
STANDARD
WIRE BASKET

GET THE MOST OUT OF YOUR NINJA FROSTVAULT™ ZONE

PRE-CHILL

For best results, load the drawer with pre-chilled items.

FILL IT UP

Lay ice on the bottom of the main cooler to keep drawer contents cold. **DO NOT** add ice to the drawer. Fill the drawer completely with food or drinks. **DO NOT** overfill.

KEEP CLOSED

Keep the drawer closed when not in use, and limit opening and closing to maintain optimal temperature.



MAXIMIZE ICE RETENTION

THE RIGHT RATIOS

For the best FrostVault™ experience, we recommend filling your cooler's main compartment with 20 cans and a minimum of 15 lbs of ice. **DO NOT** use dry ice. Ice does not need to be placed in the drawer.

PRE-CHILL THE COOLER

Before using, leave the cooler open in a cool space for a few hours or overnight. For even better results, fill with ice to lower the inside temperature. Drain when ready to use, then add fresh ice and pre-chilled contents.

PACK EFFICIENTLY & KEEP CLOSED

Fill the cooler completely with ice, food, and drinks, then use a towel to fill empty space if necessary. To retain cold temperatures and ice, keep the cooler closed. Keep shaded or cover with a tarp or blanket for best results.

COOLER STORAGE AND PLACEMENT

Ensure your cooler is on an even, level surface. **DO NOT** stand on the cooler.

After use, leave the lid and drawer open until the cooler is completely dry to prevent mold or odors. Close the lid and drawer then store the cooler in a cool, dark, and dry place.

SECURE YOUR COOLER

Open the lid and weave one tie-down strap around the designated opening on each side.



OR



Open the lid and wrap two straps, one around the designated opening on each side.

CLEANING YOUR COOLER

FIRST CLEANING


Before first use, clean the cooler with warm, soapy water. Rinse thoroughly and let air-dry.

ROUTINE CLEANING

After each use, rinse your cooler with warm, soapy water. Scrub the interior with a soft brush or cloth to remove any residue or odors. Rinse thoroughly and let air-dry.

DEEP CLEANING

Apply a paste of baking soda and water to stubborn stains or odors and scrub gently. Rinse thoroughly and let air-dry.



DRAWER CLEANING

Pull Ninja FrostVault™ Dry Zone drawer out completely, lift at an angle, and remove like you would a dresser drawer. Rinse or wipe away any sand or dirt between uses. Clean with warm, soapy water. Rinse thoroughly and let air-dry. To reinsert, put back in at an angle and close.

Remember, always ensure your cooler is completely dry before closing and storing to prevent mold and mildew growth.



We guarantee every Ninja FrostVault™ Cooler with a 5-year limited warranty against manufacturer defects.

For details visit support.ninjakitchen.com.

California Residents



WARNING: Cancer and
Reproductive Harm
www.P65Warnings.ca.gov.

UPC

© 2024 SharkNinja Operating LLC.
NINJA FROSTVAULT is a trademark of SharkNinja Operating LLC.

This product may be covered by one or more U.S. patents.
See sharkninja.com/patents for more information.

FB230Series_QSG_MP_Mv2