

HEAT AND FLAME AT THE TURN OF A DIAL

GETTING STARTED

Tips & tricks for building the ultimate outdoor experience

POWERFUL HEAD-TO-TOE OUTDOOR HEATER

FULL FLAME CONTROL PROPANE FIRE PIT







AT THE TURN OF A DIAL

NO SPARKS, EMBERS, OR ASHES

FIRESIDE360™

Ceramic Rocks

Specifically engineered and tested to use with your Ninja™ Fireside360™



Full Flame Control Propane Fire Pit

Hassle-free smokeless flames at the turn of a dial, no embers or sparks

☐ Powerful
Head-to-Toe Heater
With 360-degree heat

Complete control, no guesswork

Easily control heat and flame with 2 independent dials

GETTING STARTED

1. CERAMIC ROCKS

 Place the rocks into the bowl at top of the fire pit, covering the burner.

2. BATTERY INSTALL

- Open the the rear door and locate the yellow battery compartment on the back wall opposite the door.
- Install one AAA battery and replace the cover.

3. INSTALL TANK

 See tank install instructions in the Instruction Booklet for safe installation of the tank.

A CAUTION: Let the fire pit cool completely before touching or moving.

HOW TO IGNITE

Open door and install battery on back wall before first use.

FOLLOW THESE IGNITION INSTRUCTIONS FOR BOTH THE HEAT AND FLAME DIALS

Press the dial in and turn it counterclockwise to the IGNITE position. You will hear a clicking sound when the igniter starts to spark.

Continue to press and hold the dial in place for 10 seconds. Then release the dial and adjust the flame or heat level to your preference.

Ensure dial is turned to OFF position when not in use.



POSITION

NO SPARKS, NO EMBERS.

SAFE TO USE ON:

GRASS

STONE

WOOD



OUTDOOR HEATER & FIRE PIT



Scan here for more information

© 2025 SharkNinja Operating LLC.

FIRESIDE360, NINJA and NINJA HEATZONE are trademarks of SharkNinja Operating LLC.

This product may be covered by one or more U.S. patents. See sharkninja.com/patents for more information.

OF100Series_QSG_HangTag_REV_Mv1