

Please make sure to read the enclosed Ninja® Owner's Guide prior to using your unit.

# NINJA®

NUTRI NINJA®  
WITH AUTO-IQ®


## QUICK ASSEMBLY

### NUTRI NINJA CUPS

- 1.** Connect base to power.



- 2.** Fill cup with desired contents. Place the Pro Extractor Blades® Assembly onto the cup and twist it on tightly until you have a good seal.



- 3.** Flip cup upside down and place it onto the motor base, aligning the tabs on the cup with the motor base.

Once cup is correctly placed onto base, display will read "0".

Display will read "--" once base is properly connected to power source.



**WARNING:** Handle the Pro Extractor Blades Assembly with care, as the blades are sharp.

### AUTO-IQ

#### What is Auto-iQ?

**Auto-iQ** programs feature unique pulsing and pausing patterns to deliver consistent, even results at the touch of a button.



### CLEANING

**Dishwasher:** Containers, lids, and blade assembly are all top-rack dishwasher safe. Ensure the blade assembly is removed from the container before placing in the dishwasher.

**Hand-washing:** Wash containers, lids, and blade assembly in warm, soapy water. When washing the blade assembly, use a dishwashing utensil with a handle to avoid direct hand contact with blades. Handle blade assembly with care to avoid contact with sharp edges. Rinse and air-dry thoroughly.



**WARNING:** Handle the Pro Extractor Blades Assembly with care when washing, as the blades are sharp. Contact with the blades' edges can result in laceration.

**QUESTIONS?** We're here to help. Call **1-877-646-5288** or visit **ninjakitchen.com**