Please be sure to read the enclosed Ninja® Information Booklet prior to using your unit.

PRO COMPLETE GUICK ASSEMBLY

NUTRI NINJA[®] CUPS



1. Screw on the blade assembly clockwise until you have a tight seal.



Turn the cup upside down and lower it onto the base.

2.



3. Turn the cup clockwise to lock into place.

CLEANING

All plastic jars, lids, and blades are dishwasher safe. Place lids and blades on the TOP RACK only. **Stainless steel cup must be hand-washed.**

CAUTION: Blades are sharp. Containers are NOT intended for hot blending.



Thanks to smart settings with unique variable blending patterns, you can expect smooth, consistent, professional-quality results every time—no guesswork required.



ONE-TOUCH INTELLIGEN

AUTO-iQ[™] SMOOTH BOOST[™]

The Auto-iQ Smooth Boost button controls the level of smoothness for all types of drinks.

SMOOTH BOOST EXTRACT

For our finest breakdown of fruits and veggies, ensure **SMOOTH BOOST "YES"** is selected, then press **Auto-iQ EXTRACT.**

SMOOTH BOOST BLEND

To whip up ultra-creamy smoothies and frozen drinks ensure **SMOOTH BOOST "YES"** is selected, then press **Auto-iQ BLEND.**

TIP

If you'd like your drink to have more texture and fullness, press **SMOOTH BOOST "NO"**.



• **Great for**: Leafy greens, fibrous fruits and vegetables, seeds, and ice.



• Great for: Milkshakes, frozen drinks, smoothies, and sauces.