

Please make sure to read the enclosed Ninja® Owner's Guide prior to using your unit.


Cleaning

CUP



Keep the channel cover on the cup open so water can flow through the vacuum channel.

PITCHER & LID



Make sure water flows through the vacuum channel of the pitcher.



Keep the channel cover on the lid open so water can flow through the vacuum valve.

OVERFLOW RESERVOIR



If cleaning is necessary, remove overflow reservoir from the base. Separate bottom cover from reservoir and rinse both parts under running water.

NOTE: Make sure the overflow reservoir is completely dry before reinstalling.



DISHWASHER

The containers, lids, Micro-Juice™ Filter, and blade assemblies are all dishwasher safe. The lids and blade assemblies are top-rack dishwasher safe. Ensure the blade assemblies are removed from the containers before placing in the dishwasher.



HAND-WASHING

Hand-wash the containers, lids, Micro-Juice Filter, and blade assemblies in warm, soapy water. When washing the blade assemblies, use a dishwashing utensil with a handle to avoid direct hand contact with blades. Handle blade assemblies with care to avoid contact with sharp edges. Rinse and air-dry thoroughly.

WARNING: Always unplug the base before cleaning.

WARNING: Handle the blade assemblies with care when washing, as the blades are sharp. Contact with the blades' edges can result in laceration.

NINJA

BLENDER DUO®
WITH
Micro-Juice™ Technology

LET'S GET STARTED

WHAT'S IN THE BOX



Motor Base



72 oz. Pitcher



Pitcher Lid



Micro-Juice™ Filter



20 oz. Single-Serve Blending Cup



Pro Extractor Blades Assembly



Sealed Spout Lid



Recipe Book



Owner's Guide

Using the Unit

JUICE

Make light and refreshing juice in the pitcher. The unit will remove air then automatically switch to the program.

DRINK SAVER

DRINKSAVER

Press the DrinkSaver button after blending to remove air and keep drinks fresh up to 48 hours.



AUTO-IQ PROGRAMS

7 chef-designed automatic preset programs do the work for you.

MANUAL SETTINGS

Take control and customize your blended creations with 3 manual speeds.

Assembly & Use

USING THE PITCHER

- 1 Add ingredients, making sure to not exceed MAX LIQUID line.
- 2 Place lid on pitcher, aligning triangles on lid and pitcher handle. Then snap tabs down to lock lid in place.
- 3 Place pitcher on base and turn clockwise to align triangles on pitcher and base.
- 4 Press the power button, then select your desired program. When blending is complete, turn pitcher counterclockwise and lift to remove.

If making juice or storing with DRINKSAVER, refer to step 5.

RELEASING THE VACUUM SEAL

- 5 Pull up on the vacuum release tab on the lid. Once the vacuum seal is released, you'll be able to remove the lid.



USING THE CUP

- 1 Add ingredients, making sure to not exceed MAX LIQUID line.
- 2 Place Pro Extractor Blades® Assembly on the cup and turn clockwise to secure.
- 3 Flip cup upside down and lower it onto the base. Align the vacuum channel with the lock symbol on the back of the base. Turn cup clockwise to lock in place.
- 4 Press the power button, then select your desired program. When blending is complete, turn cup counterclockwise and lift to remove.

If storing with DRINKSAVER, refer to step 5.

RELEASING THE VACUUM SEAL

- 5 With blade assembly flat on the counter, pull up on the vacuum release tab. Once the vacuum seal is released, you'll be able to remove the blade assembly.

WARNING: Handle the Pro Extractor Blades Assembly with care, as the blades are sharp.



Two ways to store with DRINKSAVER™



ON-THE-GO CONVENIENCE

- 1 After blending in the cup, remove the blade assembly.
- 2 Twist the spout lid onto the cup, attach cup to base, then press DRINKSAVER. The unit will remove air for approximately 15 seconds until the vacuum seal is achieved.
- 3 Place vacuum-sealed drink in the refrigerator, then release the seal when you're ready to enjoy that just-made taste.



BATCH BLENDING

- 1 After blending in the pitcher, remove the lid, and pour out a glass.
- 2 Lock the lid back on the pitcher, attach pitcher to base, then press DRINKSAVER. The unit will remove air for approximately 30 seconds until the vacuum seal is achieved.
- 3 Place vacuum-sealed pitcher in refrigerator and release the seal when you're ready to enjoy another serving.

Juice Making

Our unique combination of high-speed blades, vacuum air removal, and Micro-Juice™ Filter allows you to make fresh, great-tasting, virtually pulp-free juice.

- 1 Insert Micro-Juice Filter in pitcher, aligning triangle on filter with pour spout of pitcher.
- 2 Open filter lid. Add ingredients in the order recommended in the Recipe Book. Then close the filter lid.
- 3 Place lid on pitcher, aligning triangles on lid and pitcher handle. Then snap tabs down to lock lid in place.
- 4 Place pitcher on base and turn clockwise to align triangles on pitcher and base.
- 5 Turn the unit on. Press JUICE. First the unit will remove air for approximately 30 seconds, then automatically switch to the blending program.
- 6 When blending is complete, turn pitcher clockwise and lift to remove from base.



- 7 Release vacuum seal by pulling up on the vacuum release tab on the lid.
- 8 Remove pitcher lid. With the filter still in place, pour juice into serving glasses.



PRO TIPS

- Loading order matters. See Recipe Book for more details.
- Peel citrus fruits completely.
- Cut all ingredients into 1-inch pieces.
- Use only 1/2 cup total of any highly fibrous or seeded ingredients.