

QUICK START GUIDE

+ RECIPES

BEFORE YOUR FIRST BREW


To prime your brewer:

- 1 Plug it into the wall and turn it on.
- 2 Fill the water reservoir to the Full line with fresh water and place it on the base.
- **3** Remove the Ninia Pod Adapter and slide the Sliding Lid into the closed position.
- 4 Place the empty carafe under the brew basket and run a Full Carafe. Classic Brew.

Once the brew is complete, discard the water and you're ready to brew.

If you live in a high-altitude area, running a calibration brew is required. Not running a high-altitude calibration brew in a high-altitude area will result in excessive steaming during brewing. Refer to page 7 of the Owner's **Guide for instructions on** running a high-altitude calibration brew.

HERE'S WHAT'S IN THE BOX



NINJA DUALBREW

NINJA POD ADAPTER



Comes fully installed in the brewer. Always ensure to insert it over the brew basket when brewing pods.

BREW BASKET

Comes fully installed in the brewer. It must always be inserted when brewing pods or grounds.



60 OZ. THERMAL CARAFE

Keeps coffee hot, no warming plate required.



FROTHER WHISK

Included in the box. Must be assembled on the brewer.



60 OZ. REMOVABLE WATER RESERVOIR



ALNIN SMART SCOOP™


Use this to measure coffee grounds.



PAPER FILTER KIT

Fold along the seams before inserting firmly into brew basket.

FILLING THE WATER RESERVOIR



FILL TO THE FULL LINE

Fill up to, but do not exceed. the Full line.

LOCKING AND REMOVING THE NINJA POD ADAPTER

The Ninja DualBrew Pro Coffee System comes with a unique Ninja Pod Adapter already installed on the brewer. Always ensure the adapter is installed over the brew basket.



1. Once the adapter is installed in the brewer, make sure the position indicator on the left side of the adapter is aligned with LOCK by pulling the handle toward you. Then, lift to open the handle, insert a pod. firmly push down on the handle to pierce the pod, and begin programming your brew. 2. To uninstall the adapter, remove the used pod and close the handle. Push the handle away from you so the position indicator is in the REMOVE position. Then, using the edges on the left and right, lift the adapter out of the brewer.

NOTE: The Ninja Pod Adapter is compatible only with K-Cup pods. It is not compatible with reusable K-Cup filters. If using ground coffee, use the Grounds mode with a paper or permanent filter (sold separately) to brew a single-serve size.


SLIDING LID

The sliding lid is used only when brewing loose coffee grounds. To use it, first remove the Ninja Pod Adapter. Then, using the handle on top of the brewer, slide the lid toward you until it firmly clicks into place.



POSITIONING THE WATER RESERVOIR

The water reservoir can be positioned to the right or along the back of the brewer to optimize counter space.



CUP, MUG, OR CARAFE



CUP

Pull down the cup platform to set a mug on it.



TRAVEL MUG & XL SIZES

Place an XL Cup, Travel Mug, or XL Tumbler on the base of the brewer.



CARAFE

Place the carafe on the base of the brewer.

NINJA SMART SCOOP™

The Ninja Smart Scoop is used for accurately measuring coffee grounds. The numbers beside the icons show the number of level scoops recommended for each brew size.



IMPORTANT: Always measure with level scoops of a medium grind size. Use fewer scoops when brewing decaf coffee. DO NOT use a paper filter in conjunction with a permanent filter.

SERVING SIZE	NINJA SMART SCOOP
	GROUND COFFEE
• • •	2-3 small scoops
	3-5 small scoops
	3-5 big scoops
	4-7 big scoops
Specialty 4 oz.	2 big scoops

BREW BASKET AND NINJA POD ADAPTER ASSEMBLY

BREW BASKET MUST BE INSERTED WHEN USING GROUNDS OR PODS.



GROUNDS






PODS

BREW BASKET

Must always be inserted when brewing grounds or pods.








INSERT FILTER

Fold the #4 paper cone filter along the seams, open the top fully, then insert filter firmly into the brew basket.





BREW BASKET

Must always be inserted when brewing pods or grounds. Do not insert a filter.








NINJA POD ADAPTER

Ensure adapter is in the REMOVE position before installing. Always insert over the brew basket when brewing pods.

















Ensure the brew basket and

Ninja Pod Adapter are installed

in the brewer (refer to steps on

pages 3 and 5).

Lift adapter handle to reveal

pod holder and insert a pod.


Firmly push down on the handle

to pierce the pod. Some noise

and resistance is normal.



The water outlet is completely



the coffee outlet.



IMPORTANT: Close the drip (refer to the drip stop section






Ensure the brew basket is installed and the Ninia Pod Adapter is removed. Then, insert a paper filter in the basket (refer to steps on pages 3 and 5).




Use the Ninja Smart Scoop™ to add your desired amount of coffee grounds (refer to the Smart Scoop section on page 4).



Slide the sliding lid forward, ensuring it is completely closed.

separate from the coffee outlet to ensure clean water is dispensed every time.

To enter hot water mode. turn the dial on the left side of the brewer to the water droplet icon. aligning it with the marker. You will see a change in the display.



The hot water will dispense next to



stop before brewing hot water to ensure no excessive coffee drips into the vessel on page 8).

CHOOSE A SIZE



*Approximate brew

volumes based on

Classic brew Rich

brew will produce

slightly less output.

Approximate Brew

Owner's Guide for

more information.

Volumes chart in the

Refer to the

10 oz.



12 oz.

8 oz.



XI 18 oz.

28 oz.









6 oz.





10 oz.



17 size options ranging from 2 oz. to 60 oz.

Pods cannot brew in carafe sizes.

*Approximate brew volumes based on Classic brew. Rich brew will produce slightly less output. Refer to the Approximate Brew Volumes chart

in the Owner's Guide for more information.



NOTE: Make sure to use a vessel that is big enough for the brew size you select.

CHOOSE A BREW



Smooth, wellbalanced flavor



Specially designed to brew hot over ice for freshly brewed iced coffee that is not watered down.

Always fill your vessel to the top with ice cubes before brewing Over Ice.

NOTE: DO NOT use glassware on any brew setting.



Richer than classic, with more intense flavor that stands up to milk, cream, or flavoring.



A super-rich concentrate that allows you to make coffee-based drinks like cappuccinos and lattes. Will only brew 4 oz.

$-\!-\!$ HOT WATER MODE ONLY $-\!-\!$



Two water temperatures for a variety of different foods and beverages.



BREW




Press the START BREW button to start brewing. There will be an illuminating progress bar on the display to track the status of your brew.


THE BREW MAY PAUSE ONCE OR MULTIPLE TIMES DURING THE BREW CYCLE. THAT'S OK. Pausing allows the coffee grounds to fully extract and unlock the full flavor of the brew style.

NOTE: Ensure the drip stop is open before starting your coffee brew.

DRIP STOP

The drip stop is used to close off the brew basket to prevent any coffee from dispensing. You will need to manually open and close the drip stop by moving the handle to your desired position. The drip stop can be closed and reopened at any point before, during, or after a brew.






CAN'T WAIT FOR THAT FIRST CUP?

Close the drip stop to pause the brew cycle, and pour yourself a cup. Then, reopen the drip stop to continue the brew.

STOP THE DRIPS AFTER A BREW

At the end of a brew, close the drip stop to prevent coffee dripping from the brew basket and Ninja* Pod Adapter.

FROTHING






- 1. Add milk to your cup until it is about 1/3 full.
 - * For cold froth, continue to Step 2.
 - For hot froth, microwave for 45-60 seconds.



2. Swing the arm of the frother toward the front of the brewer. Install the frother whisk by twisting it to the right.



- **3.** Hold the cup under the frother and submerge the whisk just below the surface of the milk. Press and hold the button on top of the frother and froth for 30-45 seconds.
- **4.** Remove the frother whisk by twisting it to the left. Keep your cup below the whisk while you carry it to your sink or dishwasher for easy cleaning.



WARNING: To avoid contact with steam and hot surfaces, **DO NOT** reach across top of brewer to froth.

GUIDE TO KEEPING COFFEE HOT

The type of cup you brew into can greatly influence the temperature of your coffee when drinking. For a hotter cup, use the Hot Water mode on BOIL to conveniently pre-warm the cup.

		CERAMIC CUP		PAPER CUP
Cup Temperature	Room temperature	Pre-warmed with hot water	Pre-warmed in microwave with milk	Room temperature
Drinking Temperature	Hot	Hotter	Hotter	Hottest
Why is there a difference?	A cold ceramic mug will steal heat from the coffee as it warms itself up.	If the mug is already warm, it will not steal as much heat from the coffee.	Just like your cold mug, cold milk lowers the temperature of your coffee.	Unlike a ceramic mug, a thinner paper cup does not steal substantial heat from the coffee.

NOTE: DO NOT put the carafe in the microwave.

CAPPUCCINO-STYLE COFFEE

SPECIALTY

Brew: Specialty **Makes:** 1 serving (12-ounce cup)

INGREDIENTS

2 Ninja Big Scoops (4 tablespoons) around coffee

½ cup milk

Sweetener, as desired

Ground cinnamon, for garnish

DIRECTIONS

- 1. Following the measurement provided, place the ground coffee into the filter.
- 2. Pour milk into a 12-ounce mug. Microwave for 45-60 seconds, then froth for 30 seconds.
- **3.** Set the mug containing frothed milk in place to brew.
- 4. Press the BREW STYLE button to select SPECIALTY, then press the START BREW button to begin the brew.
- 5. When brew is complete, sweeten and garnish as desired.

ICED NUTTY COCOA LATTE

SPECIALTY

Brew: Specialty **Makes:** 1 serving (18-ounce cup)

INGREDIENTS

2 Ninja Big Scoops (4 tablespoons) around coffee

2 tablespoons chocolate syrup, plus more for garnish

1 tablespoon caramel syrup, plus more for garnish

2 cups ice

½ cup milk

1 tablespoon peanut butter

DIRECTIONS

- 1. Following the measurement provided, place the ground coffee into the filter.
- 2. Add chocolate syrup, caramel syrup, and ice to an 18-ounce cup and set in place to brew.
- **3.** Press the BREW STYLE button to select SPECIALTY, then press the START BREW button to begin the brew.
- 4. While coffee is brewing, place milk and peanut butter in a large mug, stir to combine, then microwave for 45-60 seconds.
- **5.** When brew is complete, stir to combine.
- 6. Froth milk mixture for 30 seconds, then gently pour over coffee. Garnish as desired.

-	
-	

Notes



For questions or to register your product, contact us at 1-877-646-5288 or visit us online at ninjakitchen.com











@ninjakitchen

CFP305_QSG_REV_MV26
© 2022 SharkNinja Operating LLC
NINJA is a registered trademark of SharkNinja Operating LLC.
NINJA SMART SCOOP is a trademark of SharkNinja Operating LLC.
All other marks, including KEURIG and K-CUP, are trademarks of their respective owners.