

Please make sure to read the enclosed Ninja® Owner's Guide prior to using your unit.

NINJA®

AIR FRYER

QUICK START GUIDE













+ COOKING CHARTS
+ 20 IRRESISTIBLE RECIPES

USING YOUR AIR FRYER'S FUNCTIONS

Pull crispy meals out of thin air.

The Ninja® Air Fryer circulates super-hot air around your food to remove moisture from its surface to give it that golden-brown, crispy finish.

PREHEAT RECOMMENDATION: Let the unit preheat for 3 minutes before adding ingredients.

FUNCTION	ACCESSORY REQUIRED	TEMP	TIME
<p>AIR FRY</p> <p>Crisp without the guilt of deep-fried food.</p>	 <p>Crisper Plate</p>	 <p>Adjust temp as needed</p>	 <p>Set time, in minutes, and press START/PAUSE to begin</p>
<p>ROAST</p> <p>Bake and roast your favorite foods traditionally made in an oven without the crisper plate.</p>	 <p>Crisper Plate</p>	 <p>Adjust temp as needed</p>	 <p>Set time, in minutes, and press START/PAUSE to begin</p>
<p>REHEAT</p> <p>Perfect for reviving your leftovers.</p>	 <p>Crisper Plate</p>	 <p>Adjust temp as needed</p>	 <p>Set time, in minutes, and press START/PAUSE to begin</p>
<p>DEHYDRATE</p> <p>Gently and slowly remove moisture from foods to create delicious homemade snacks.</p>	 <p>Crisper Plate</p>	 <p>Adjust temp as needed</p>	 <p>Set time in 15-minute increments, and press START/PAUSE to begin</p>


AIR FRY 101

For inspiring recipes and cooking charts, visit ninjakitchen.com.




PREHEAT

For best cooking and crisping results, always preheat your Ninja Air Fryer for 3 minutes.



CRISPER PLATE

The crisper plate promotes overall browning. We recommend using it every time you air fry.



SHAKE OR TOSS

For best results, frequently shake your food or toss it with silicone-tipped tongs to get it as crispy as you'd like.

AIR FRY TIPS & TRICKS



SHAKE, SHAKE, SHAKE

Check food and shake basket frequently for even browning. Remove food at desired level of brownness.



CONVERT OVEN RECIPES

Convert oven recipes by using the Roast function and reducing the cooking temperature by 25°F. Check food frequently to avoid overcooking.



FREESTYLING RECIPES

If you are cooking less food than the recipe calls for, remember to reduce the cook time. If you're cooking a bit more, increase the cook time. Check food frequently.




AIR FRYING FRESH INGREDIENTS

For best results with fresh vegetables, use at least 1 tablespoon of oil. Add a little more to achieve that perfect level of crispiness.



DON'T OVERCROWD

Evenly arrange and space ingredients out to ensure consistent browning.



SECURE YOUR FOOD

Keep light foods from being blown around by the fan by securing them with toothpicks.



MORE EVEN BROWNING

Use an oil spritzer to evenly coat ingredients for more even browning.

DEHYDRATE TIPS & TRICKS



SLICING

Use a mandoline slicer to get consistent, thin fruit and vegetable slices. Fruits and veggies should be sliced as thinly as possible without falling apart.



PREVENT OXIDATION

Fruits like apples and pears quickly oxidize when cut. To delay oxidation, soak them in water for 5 minutes with a squeeze of lemon juice.



DRY BEFORE YOU DEHYDRATE

Fruits and vegetables should be patted as dry as possible before being placed into the basket.



DON'T OVERLAP

Lay ingredients flat and close together to optimize space. Individual pieces should not overlap or be stacked.



TRIM THE FAT

Before dehydrating meat or poultry, make sure to trim off all fat, as it does not dry out and could turn rancid.



PASTEURIZING JERKY

Before dehydrating meats and fish, use the Roast function at 330°F for 1 minute to fully pasteurize them.



HOW LONG TO DEHYDRATE?

Most fruits and veggies take 6-8 hours, while jerky takes 5-7 hours. The longer you dehydrate ingredients, the crispier they will get.



STORAGE

To maximize longevity, store dehydrated foods at room temperature in an airtight container up to 2 weeks.

Air Fry Cooking Chart

INGREDIENT	AMOUNT	PREPARATION
VEGETABLES		
Asparagus	1 bunch	Whole, stems trimmed
Beets	6 small or 4 large (about 2 lbs)	Whole
Bell peppers (for roasting)	4 peppers	Whole
Broccoli	1 head	Cut in 1-inch florets
Brussels sprouts	1 lb	Cut in half, stem removed
Butternut squash	1-1 1/2 lbs	Cut in 1-2-inch pieces
Carrots	1 lb	Peeled, cut in 1/2-inch pieces
Cauliflower	1 head	Cut in 1-inch florets
Corn on the cob	4 ears	Whole ears, husks removed
Green beans	1 bag (12 oz)	Trimmed
Kale (for chips)	6 cups, packed	Torn in pieces, stems removed
Mushrooms	8 oz	Rinsed, cut in quarters
Potatoes, russet	1 1/2 lbs	Cut in 1-inch wedges
	1 lb	Hand-cut fries*, thin
	1 lb	Hand-cut fries*, thick
	4 whole (6-8 oz)	Pierced with fork 3 times
Potatoes, sweet	1 1/2 lbs	Cut in 1-inch chunks
	4 whole (6-8 oz)	Pierced with fork 3 times
Zucchini	1 lb	Cut in quarters lengthwise, then cut in 1-inch pieces
POULTRY		
Chicken breasts	2 breasts (3/4-1 1/2 lbs each)	Bone in
	2 breasts (1/2-3/4 lb each)	Boneless
Chicken thighs	4 thighs (6-10 oz each)	Bone in
	4 thighs (4-8 oz each)	Boneless
Chicken wings	2 lbs	Drumettes & flats
FISH & SEAFOOD		
Crab cakes	2 cakes (6-8 oz each)	None
Lobster tails	4 tails (3-4 oz each)	Whole
Salmon fillets	2 fillets (4 oz each)	None
Shrimp	16 large	Whole, peeled, tails on


*After cutting potatoes, allow raw fries to soak in cold water for at least 30 minutes to remove unnecessary starch. Pat fries dry. The drier the fries, the better the results.

TOSS IN OIL	TEMP	COOK TIME
2 tsp	390°F	8-12 mins
None	390°F	45-60 mins
None	400°F	25-30 mins
1 Tbsp	390°F	10-12 mins
1 Tbsp	390°F	15-20 mins
1 Tbsp	390°F	20-25 mins
1 Tbsp	390°F	13-16 mins
2 Tbsp	390°F	15-20 mins
1 Tbsp	390°F	12-15 mins
1 Tbsp	390°F	8-10 mins
None	300°F	8-10 mins
1 Tbsp	390°F	7-9 mins
1 Tbsp	390°F	18-20 mins
1/2-3 Tbsp, canola	390°F	20-24 mins
1/2-3 Tbsp, canola	390°F	23-26 mins
None	390°F	30-35 mins
1 Tbsp	390°F	15-20 mins
None	390°F	30-35 mins
1 Tbsp	390°F	15-18 mins
Brushed with oil	375°F	25-35 mins
Brushed with oil	375°F	18-22 mins
Brushed with oil	390°F	22-28 mins
Brushed with oil	390°F	18-22 mins
1 Tbsp	390°F	22-26 mins
Brushed with oil	350°F	12-15 mins
None	375°F	5-8 mins
Brushed with oil	390°F	10-13 mins
1 Tbsp	390°F	7-10 mins

For best results, shake or toss often.

We recommend frequently checking your food and shaking or tossing it to ensure desired results.

Use these cook times as a guide, adjusting to your preference.



Shake your food

OR



Toss with silicone-tipped tongs

Air Fry Cooking Chart, continued

INGREDIENT	AMOUNT	PREPARATION
BEEF		
Burgers	4 quarter-pound patties, 80% lean	1 inch thick
Steaks	2 steaks (8 oz each)	Whole
PORK & LAMB		
Bacon	4 strips, cut in half	None
Pork chops	2 thick-cut, bone-in chops (10-12 ounces each)	Bone in
	4 boneless chops (8 ounces each)	Boneless
Pork tenderloins	2 tenderloins (1-1 1/2 lbs each)	Whole
Sausages	4 sausages	Whole
FROZEN FOODS		
Chicken cutlets	5 cutlets	None
Chicken nuggets	1 box (12 oz)	None
Fish fillets	1 box (6 fillets)	None
Fish sticks	18 fish sticks (11 ounces)	None
French fries	1 lb	None
French fries	2 lbs	None
Mozzarella sticks	1 box (11 oz)	None
Pot stickers	1 bag (24 oz, 20 count)	None
Pizza rolls	1 bag (20 oz, 40 count)	None
Popcorn shrimp	1 box (14-16 ounces)	None
Frozen sweet potato fries	1 lb (20 oz)	None
Tater tots	1 lb	None

TOSS IN OIL	TEMP	COOK TIME
None	375°F	8-10 mins
None	390°F	10-20 mins
None	350°F	8-10 mins
Brushed with oil	375°F	15-17 mins
Brushed with oil	375°F	14-17 mins
Brushed with oil	375°F	25-35 mins
None	390°F	8-10 mins
None	390°F	18-21 mins
None	390°F	10-13 mins
None	390°F	14-16 mins
None	390°F	10-13 mins
None	350°F	20-25 mins
None	360°F	28-32 mins
None	375°F	8-10 mins
None	390°F	12-14 mins
None	390°F	12-15 mins
None	390°F	9-11 mins
None	375°F	20-22 mins
None	360°F	18-22 mins

For best results, shake or toss often.

We recommend frequently checking your food and shaking or tossing it to ensure desired results.

Use these cook times as a guide, adjusting to your preference.



Shake your food

OR



Toss with silicone-tipped tongs

Dehydrate Chart

INGREDIENTS	PREPARATION
FRUITS & VEGETABLES	
Apples	Core removed, cut in 1/8-inch slices, rinsed in lemon water, patted dry
Asparagus	Cut in 1-inch pieces, blanched
Bananas	Peeled, cut in 3/8-inch slices
Beets	Peeled, cut in 1/8-inch slices
Eggplant	Peeled, cut in 1/4-inch slices, blanched
Fresh herbs	Rinsed, patted dry, stems removed
Ginger root	Cut in 3/8-inch slices
Mangoes	Peeled, cut in 3/8-inch slices, pit removed
Mushrooms	Cleaned with soft brush (do not wash)
Pineapple	Peeled, cored, cut in 3/8-1/2-inch slices
Strawberries	Cut in half or in 1/2-inch slices
Tomatoes	Cut in 3/8-inch slices or grated; steam if planning to rehydrate
MEAT, POULTRY, FISH	
Beef jerky	Cut in 1/4-inch slices, marinated overnight (refer to Beef Jerky recipe, page 19)
Chicken jerky	Cut in 1/4-inch slices, marinated overnight (refer to Beef Jerky recipe, page 19)
Turkey jerky	Cut in 1/4-inch slices, marinated overnight (refer to Beef Jerky recipe, page 19)
Salmon jerky	Cut in 1/4-inch slices, marinated overnight (refer to Beef Jerky recipe, page 19)

TEMP	DEHYDRATE TIME
135°F	7-8 hours
135°F	6-8 hours
135°F	8-10 hours
135°F	6-8 hours
135°F	6-8 hours
135°F	4 hours
135°F	6 hours
135°F	6-8 hours
135°F	6-8 hours
135°F	6-8 hours
135°F	6-8 hours
135°F	6-8 hours
150°F	5-7 hours
150°F	5-7 hours
150°F	5-7 hours
150°F	3-5 hours

FROZEN FRENCH FRIES

COOK: 20-25 MINUTES | MAKES: 5-6 SERVINGS

INGREDIENTS

1 pound frozen French fries

TIP: For crispier fries, shake or toss with silicone-tipped tongs 2 separate times during cooking.



Insert crisper plate in basket and insert basket in unit. Preheat the unit by selecting AIR FRY, setting the temperature to 350°F, and setting the time to 3 minutes. Select START/PAUSE to begin.



After 3 minutes, add fries to basket; reinsert basket. Select AIR FRY, set temperature to 350°F, and set time to 23 minutes. Select START/PAUSE to begin.



After 10 minutes, remove basket from unit and shake fries or toss them with silicone-tipped tongs. Reinsert basket to resume cooking for 10 more minutes. Check for desired crispiness, cooking for an additional 3 minutes if needed. When cooking is complete, serve with your favorite dipping sauce.

HAND-CUT FRIES

BASICS

PREP: 10 MINUTES | **COOK:** 20-24 MINUTES | **MAKES:** 5-6 SERVINGS

INGREDIENTS

1 pound russet or Idaho potatoes, cut in thin 2-inch strips
1/2-3 tablespoons canola oil

DIRECTIONS

- 1 Soak cut potatoes in cold water for 30 minutes to remove excess starch. Drain well, then pat with a paper towel until very dry.
- 2 Place all ingredients into a large mixing bowl; toss to combine. Use at least 1/2 tablespoon oil. For crispier results, use up to 3 tablespoons oil.
- 3 Insert crisper plate in basket and basket in unit. Preheat unit by selecting AIR FRY, setting the temperature to 390°F, and setting the time to 3 minutes. Select START/PAUSE to begin.
- 4 After 3 minutes, place fries on the crisper plate; reinsert basket. Select AIR FRY, set temperature to 390°F, and set time to 25 minutes. Select START/PAUSE to begin.
- 5 After 10 minutes, simply remove the basket from the unit and shake fries or toss them with silicone-tipped tongs. Reinsert the basket to resume cooking.
- 6 Check fries after 20 minutes. For crispier fries, continue cooking for up to 25 minutes.
- 7 When cooking is complete, serve immediately with your favorite dipping sauce.



TIP: Shaking the fries is key for getting them crisp and golden brown, so shake or toss with silicone-tipped tongs frequently.

JALAPEÑO POPPERS

PREP: 15 MINUTES | **COOK:** 15 MINUTES | **MAKES:** 8 SERVINGS

INGREDIENTS

- 1/2 block (4 ounces) cream cheese, softened
- 1/2 bag (4 ounces) shredded cheddar cheese
- 1 tablespoon kosher salt
- 8 jalapeño peppers, cut in half lengthwise, stems left on, seeds and membranes removed
- 8 strips uncooked bacon

DIRECTIONS

- 1** In a small mixing bowl, mix together the cream cheese, cheddar, and salt.
- 2** Using a small teaspoon or coffee spoon, fill each jalapeño half with the cheese mixture, making sure not to overfill.
- 3** Place 2 pepper halves together, then wrap each pepper with 1 piece of bacon. Repeat with remaining peppers.
- 4** Insert crisper plate in basket and basket in unit. Then preheat the unit by selecting AIR FRY, setting the temperature to 360°F, and setting the time to 3 minutes. Select START/PAUSE to begin.
- 5** After 3 minutes, place peppers on crisper plate; reinsert basket. Select AIR FRY, set temperature to 360°F, and set time to 15 minutes. Select START/PAUSE to begin.
- 6** After 7 minutes, remove basket from unit and rotate peppers to ensure the bacon crisps on all sides. Reinsert basket to resume cooking.
- 7** Cooking is complete when bacon is crisp and peppers are beginning to shrivel. Remove peppers and allow to cool for 10 minutes, then serve warm.

BRUSSELS SPROUTS & BACON

BASICS

PREP: 10 MINUTES | **COOK:** 18-20 MINUTES | **MAKES:** 4-6 SERVINGS

INGREDIENTS

1 pound Brussels sprouts,
cut in half
5 strips uncooked bacon,
cut in 1/8-inch pieces
2 teaspoons garlic powder
2 teaspoons black pepper
4 teaspoons kosher salt
1 tablespoon olive oil

DIRECTIONS

- 1 Place all ingredients into a large mixing bowl; toss to combine.
- 2 Insert crisper plate in basket and basket in unit. Preheat unit by selecting AIR FRY, setting the temperature to 390°F, and setting the time to 3 minutes. Select START/PAUSE to begin.
- 3 After 3 minutes, place Brussels sprouts mixture on the crisper plate; reinsert basket. Select AIR FRY, set temperature to 390°F, and set time to 20 minutes. Select START/PAUSE to begin.
- 4 Halfway through cooking, remove basket from unit and toss Brussels sprouts. Reinsert basket and to resume cooking.
- 5 Begin checking Brussels sprouts for crispiness after 18 minutes and continue cooking for up to an additional 2 minutes if desired. When cooking is complete, serve immediately.



CRISPY POTATOES WITH SPICY MAYO

PREP: 15 MINUTES | **COOK:** 25 MINUTES | **MAKES:** 4-6 SERVINGS

INGREDIENTS

1 pound baby potatoes,
cut in quarters
2 tablespoons extra virgin
olive oil
3 teaspoons hot paprika, divided
1 tablespoon plus 1 teaspoon
smoked paprika, divided
1 tablespoon plus 1 teaspoon
garlic powder, divided
4 teaspoons kosher salt, divided
1/2 cup mayonnaise
2 tablespoons sundried
tomato paste
2 tablespoons sherry or
white wine vinegar
1/2 cup fresh parsley,
finely chopped, for garnish

DIRECTIONS

- 1** In a large mixing bowl, toss the potatoes in olive oil, 2 teaspoons hot paprika, 1 tablespoon smoked paprika, 1 tablespoon garlic powder, and 2 teaspoons salt.
- 2** Insert crisper plate in basket and basket in unit. Preheat unit by selecting AIR FRY, setting the temperature to 360°F, and setting the time to 3 minutes. Select START/PAUSE to begin.
- 3** After 3 minutes, place seasoned potatoes on crisper plate; reinsert basket. Select AIR FRY, set temperature to 360°F, and set time to 25 minutes. Select START/PAUSE to begin.
- 4** Halfway through cooking, remove basket from unit and toss potatoes. Reinsert basket to resume cooking.
- 5** While potatoes are cooking, mix together mayonnaise, tomato paste, vinegar, and remaining seasonings in a small bowl.
- 6** When cooking is complete, garnish potatoes with parsley and serve with spicy mayo.

FRIED PICKLES

BASICS

PREP: 10 MINUTES | **COOK:** 10 MINUTES | **MAKES:** 4-6 SERVINGS

INGREDIENTS

20 dill pickle slices
1/4 cup all-purpose flour
1/8 teaspoon baking powder
3 tablespoons beer or seltzer water
1/8 teaspoon kosher salt
2 tablespoons water, plus more if needed
2 tablespoons cornstarch
1 1/2 cups panko bread crumbs
1 teaspoon paprika
1 teaspoon garlic powder
1/4 teaspoon cayenne pepper
1/4 cup canola oil, divided

DIRECTIONS

- 1 Pat the pickle slices dry and place them on a dry plate in the freezer.
- 2 In a mixing bowl, stir together flour, baking powder, beer or seltzer water, salt, and 2 tablespoons water. Batter should be the consistency of cake batter. If batter is too thick, add more water, 1 teaspoon at a time.
- 3 Place cornstarch in a shallow bowl. Combine bread crumbs, paprika, garlic powder, and cayenne pepper in a separate shallow bowl.
- 4 Remove pickles from freezer. Dredge each one in cornstarch. Tap off excess, then coat in batter. Then coat evenly with bread crumbs.
- 5 Insert crisper plate in basket and basket in unit. Preheat unit by selecting AIR FRY, setting the temperature to 360°F, and setting the time to 3 minutes. Select START/PAUSE to begin.
- 6 After 3 minutes, place breaded pickles on crisper plate. Spray or gently brush generously with canola oil. Insert basket in unit.
- 7 Select AIR FRY, set temperature to 360°F, and set time to 10 minutes. Select START/PAUSE to begin.
- 8 Halfway through cooking, remove basket from unit and flip pickles and spray or gently brush the other side. Reinsert basket to resume cooking.
- 9 When cooking is complete, serve immediately with your favorite dipping sauce.



BASICS

ZUCCHINI STICKS WITH MARINARA SAUCE

PREP: 25 MINUTES | **FREEZE:** 30–45 MINUTES
COOK: 20 MINUTES | **MAKES:** 8 SERVINGS

INGREDIENTS

2 large zucchini, cut in sticks
1/4 inch thick and 3 inches long
2 teaspoons kosher salt
1 1/2 cups all-purpose flour
2 eggs, beaten
2 cups seasoned bread crumbs
1/4 cup grated Parmesan cheese
1 tablespoon garlic powder
2 teaspoons onion powder
1/2 cup marinara sauce,
for serving

DIRECTIONS

- 1 Place zucchini sticks on a plate and sprinkle with salt. Allow to sit at room temperature for 15 minutes to remove excess water. Pat dry.
- 2 Place flour in a shallow bowl. Place eggs in another shallow bowl. Combine bread crumbs, Parmesan cheese, garlic powder, and onion powder into a third bowl or plate, stirring to combine.
- 3 Working in small batches, toss zucchini sticks in flour. Tap off excess, then coat in egg. Then toss with bread crumbs, coating evenly. Set breaded zucchini sticks on a dry plate.
- 4 Cover plate with plastic wrap and freeze for 30 to 45 minutes, or until the breading has hardened.
- 5 Insert crisper plate in basket and basket in unit. Preheat unit by selecting AIR FRY, setting the temperature to 360°F, and setting the time to 3 minutes. Select START/PAUSE to begin.
- 6 After 3 minutes, place zucchini sticks on crisper plate. Select AIR FRY, set temperature to 360°F, and set time to 20 minutes. Select START/PAUSE to begin.
- 7 Halfway through cooking, remove basket from unit and toss zucchini sticks. Reinsert basket to resume cooking.
- 8 Cooking is complete when the sticks are evenly browned on all sides. Add more time if necessary. Serve immediately with marinara sauce.



BEEF JERKY

BASICS

PREP: 15 MINUTES | **MARINATE:** 8 HOURS | **COOK:** 5–8 HOURS
MAKES: 3 CUPS (6 OUNCES) DRIED JERKY

INGREDIENTS

1/4 cup soy sauce
2 tablespoons
Worcestershire sauce
2 tablespoons dark brown sugar
1 teaspoon ground black pepper
1 teaspoon garlic powder
1 teaspoon onion powder
1 teaspoon paprika
2 teaspoons kosher salt
1 pound uncooked beef eye
of round, cut in 1/4-inch slices

DIRECTIONS

- 1 Whisk together all ingredients, except beef. Place mixture into large resealable plastic bag.
- 2 Add beef to bag and rub to coat. Marinate in refrigerator for 8 hours or overnight.
- 3 Strain meat; discard excess marinade.
- 4 Remove the crisper plate from the basket. Lay half the sliced meat flat on the bottom of the basket in one layer. Place the crisper plate on top of the meat. Place remaining meat on the crisper plate.
- 5 Insert basket in unit. Select DEHYDRATE, set temperature to 150°F, and set time to 7 hours. Select START/PAUSE to begin. Check after 5 hours, then cook until desired texture is reached.
- 6 When cooking is complete, remove jerky and store in an airtight container.



BREAKFAST

FRENCH TOAST BREAD PUDDING

PREP: 10 MINUTES | **CHILL:** 30 MINUTES–8 HOURS
COOK: 40 MINUTES | **MAKES:** 4–6 SERVINGS

INGREDIENTS

4 eggs
¾ cup heavy cream
1 tablespoon sugar
2 teaspoons orange liqueur
1 teaspoon kosher salt
¼ teaspoon ground cloves
9 precooked pecan sticky
or cinnamon buns
(2 ¼ ounces each),
cut in quarters
½ cup dried cherries

DIRECTIONS

- 1** In a large mixing bowl, whisk together eggs, heavy cream, and sugar until smooth. Add orange liqueur, salt, and ground cloves and whisk to incorporate.
- 2** Add sticky buns and cherries to the egg mixture and liberally coat. Cover the bowl and refrigerate for 30 minutes to 8 hours.
- 3** Remove the crisper plate from the basket and insert basket in unit. Preheat the unit by selecting ROAST, setting the temperature to 400°F, and setting the time to 3 minutes. Select START/PAUSE to begin.
- 4** After 3 minutes, remove the basket and spray liberally with cooking spray. Pour the bread mixture directly into the bottom of the basket. Pat the mixture down evenly using a spatula, then reinsert basket.
- 5** Select ROAST, set temperature to 325°F, and set time to 45 minutes. Select START/PAUSE to begin.
- 6** After 20 minutes, remove basket from unit and cover the surface of bread pudding with aluminum foil to allow the eggs to fully set without burning the tops. Reinsert basket to resume cooking.
- 7** Check every 5 minutes. Cooking is complete when a toothpick fully inserted comes out clean and the internal temperature reaches 160°F. Remove basket and let bread pudding cool for 10 minutes before serving.

BACON & PEPPER BREAKFAST HASH

BREAKFAST

PREP: 15 MINUTES | **COOK:** 43-45 MINUTES | **MAKES:** 4 SERVINGS

INGREDIENTS

1/2 package (8 ounces) uncooked
bacon, cut in 1/4-inch pieces
1 small yellow onion,
peeled, diced
1 red bell pepper, diced
2 russet potatoes, peeled, diced
1 teaspoon paprika
1 teaspoon black pepper,
plus more for seasoning
1 teaspoon celery or garlic salt
1 teaspoon kosher salt,
plus more for seasoning
4 eggs

DIRECTIONS

- 1** Remove the crisper plate from the basket and insert basket in unit. Preheat the unit by selecting ROAST, setting the temperature to 300°F, and setting the time to 3 minutes. Select START/PAUSE to begin.
- 2** After 3 minutes, add bacon to the basket. Select ROAST, set temperature to 300°F, and set time to 45 minutes. Select START/PAUSE to begin. Cook for 5 minutes, or until bacon is crispy, stirring occasionally.
- 3** Add the onion, pepper, potatoes, and spices to the basket. Stir to incorporate, then insert basket in unit.
- 4** Cook for 35 minutes, stirring occasionally, until potatoes are cooked through and golden brown.
- 5** Once vegetables are cooked, remove basket from unit and crack four eggs onto the surface of the hash. Season with additional salt and pepper, to taste. Reinsert basket to resume cooking.
- 6** Cook for 3 to 5 minutes, or until egg whites are set, adding more time if needed. Serve immediately.

BREAKFAST POCKETS

PREP: 15 MINUTES | **COOK:** 39 MINUTES | **MAKES:** 4 SERVINGS

INGREDIENTS

2 sheets puff pastry (one 17.25 ounce box), room temperature
1 package (6 ounces) ground breakfast sausage, crumbled
2 eggs, lightly beaten
1 teaspoon kosher salt
1/2 teaspoon ground black pepper
1 cup shredded cheddar cheese
2 tablespoons canola oil

DIRECTIONS

- 1 Cut each puff pastry sheet into 4 equal-sized rectangles; set aside.
- 2 Remove crisper plate from basket. Place crumbled sausage in basket. Insert basket in unit.
- 3 Select ROAST, set temperature to 375°F, and set time to 15 minutes. Select START/PAUSE to begin. Check sausage every 2 or 3 minutes, breaking apart larger pieces with a wooden spoon.
- 4 After 10 minutes, remove basket from unit and pour eggs into basket. Stir to evenly incorporate with the sausage. Reinsert basket to resume cooking. Allow eggs to cook for about 5 minutes, checking frequently, until they have the consistency of scrambled eggs. Then transfer sausage and egg mixture to a plate to cool slightly. Season with salt and pepper.
- 5 Divide sausage and egg mixture evenly between 4 rectangles of puff pastry. Top each with 1/4 cup shredded cheese. Place another piece of puff pastry on top of each, crimping pastry sheets together with a fork. Brush each assembled pocket gently with canola oil.
- 6 Insert crisper plate in basket and place one pocket on the crisper plate. Insert basket in unit. Select AIR FRY, set temperature to 400°F, and set time to 6 minutes. Select START/PAUSE to begin.
- 7 Cooking is complete when pastry has risen and the top is golden brown.
- 8 Repeat steps 6 and 7 with remaining pockets.

SPICE-RUBBED CHICKEN BREASTS WITH CHIMICHURRI

MAINS

PREP: 15 MINUTES | **COOK:** 35 MINUTES | **MAKES:** 2 SERVINGS

INGREDIENTS


2 teaspoons kosher salt
1 tablespoon ground paprika
1 tablespoon chili powder
1 tablespoon ground fennel
1 teaspoon fresh cracked black pepper
1 teaspoon onion powder
1 teaspoon garlic powder
1 teaspoon ground cumin
2 uncooked bone-in, skin-on chicken breasts (3/4-1 1/4 pounds each)
1 tablespoon canola oil

CHIMICHURRI

1/4 cup olive oil
1/2 bunch fresh cilantro
1/2 bunch fresh parsley
1 shallot, peeled, cut in quarters
4 cloves garlic, peeled
Zest and juice of 1 lemon
1 teaspoon kosher salt

DIRECTIONS

- 1 In a small mixing bowl, stir together all dried spices.
- 2 Pat the chicken breasts dry. Coat with canola oil, then season them liberally on all sides with spice mixture.
- 3 Insert crisper plate in basket and basket in unit. Preheat the unit by selecting AIR FRY, setting the temperature to 300°F, and setting the time to 3 minutes. Select START/PAUSE to begin.
- 4 After 3 minutes, add chicken to the basket. Select AIR FRY, set temperature to 300°F, and set time to 35 minutes. Select START/PAUSE to begin.
- 5 While chicken is cooking, combine the chimichurri ingredients in a food processor and process until finely minced, being careful not to over-process.
- 6 Cooking is complete when internal temperature reaches 165°F. Add more time if necessary. Remove basket and let chicken cool for 5 minutes, then serve with a generous amount of chimichurri.



MAINS

LEMON & HERB PANKO CRUSTED COD

PREP: 5 MINUTES | **COOK:** 12 MINUTES | **MAKES:** 2 SERVINGS

INGREDIENTS

2 uncooked cod fillets
(6 ounces each)
3 teaspoons kosher salt, divided
³/₄ cup panko bread crumbs
2 tablespoons butter, melted
¹/₄ cup fresh parsley, minced
Zest and juice of 1 lemon

DIRECTIONS

- 1** Insert crisper plate in basket and basket in unit. Preheat the unit by selecting AIR FRY, setting the temperature to 360°F, and setting the time to 3 minutes. Select START/PAUSE to begin.
- 2** While unit is preheating, season each cod fillet on all sides with 1 teaspoon salt.
- 3** In a mixing bowl, stir together bread crumbs, butter, parsley, lemon zest and juice, and remaining 1 teaspoon salt. Mix thoroughly so the bread crumbs are coated with lemon and butter.
- 4** Generously pack the top of each cod fillet with seasoned breading.
- 5** After 3 minutes, place the fillets, breaded side up, in the basket. Insert basket in unit.
- 6** Select AIR FRY, set temperature to 360°F, and set time to 15 minutes. Select START/PAUSE to begin.
- 7** Cook for 12 to 15 minutes. Cooking is complete when the top is evenly browned and internal temperature reaches 145°F. Remove fillets and serve immediately.

PORK LOIN WITH VEGETABLES

MAINS

PREP: 15 MINUTES | **COOK:** 40 MINUTES | **MAKES:** 2 SERVINGS

INGREDIENTS

1 medium zucchini,
cut in 1-inch pieces
1 medium yellow squash,
cut in 1-inch pieces
1 red onion, peeled,
cut in eighths
3 teaspoons kosher salt, divided
3 teaspoons ground black
pepper, divided
2 teaspoons fresh oregano,
chopped
1 tablespoon olive oil
1 uncooked pork loin roast
(24 ounces)

DIRECTIONS

- 1** In a large mixing bowl, toss zucchini, squash, and onion (making sure to separate the onion layers) with 1 teaspoon salt, 1 teaspoon pepper, oregano, and olive oil. Season the pork loin on all sides with the remaining salt and pepper.
- 2** Insert crisper plate in basket and basket in unit. Preheat the unit by selecting AIR FRY, setting the temperature to 325°F, and setting the time to 3 minutes. Select START/PAUSE to begin.
- 3** After 3 minutes, place vegetables on the crisper plate. Lay the pork, fat-side down, on top of the vegetables.
- 4** Select AIR FRY, set temperature to 325°F, and set time to 40 minutes. Select START/PAUSE to begin.
- 5** After 20 minutes, remove basket from unit and flip pork loin. Stir vegetables. Reinsert basket to resume cooking.
- 6** Cooking is complete when internal temperature reaches 145°F. Remove basket and let the pork cool for 5 to 10 minutes before serving.

MAINS

FRENCH BREAD PIZZA

PREP: 5 MINUTES | **COOK:** 8 MINUTES | **MAKES:** 4 SERVINGS

INGREDIENTS

1 (12-inch) baguette, cut in half lengthwise, then cut in half across to make 4 pizza crusts
1/2 cup pizza or marinara sauce
1 cup shredded mozzarella cheese, divided

TOPPINGS

12 pieces sliced pepperoni or sausage
1/2 green bell pepper, thinly sliced
2 button mushrooms, thinly sliced
Black olives

GARNISHES

Grated Parmesan cheese
Dried oregano
Crushed red pepper

DIRECTIONS

- 1 Coat each piece of bread with 2 tablespoons pizza sauce, allowing bread to absorb sauce.
- 2 Cover each piece of bread with 2 tablespoons cheese. Add desired toppings, then cover with the remaining cheese.
- 3 Insert crisper plate in basket and basket in unit. Preheat unit by selecting AIR FRY, setting the temperature to 400°F, and setting the time to 3 minutes. Select START/PAUSE to begin.
- 4 After 3 minutes, place 2 pizzas on crisper plate; insert basket in unit. Select AIR FRY, set temperature to 400°F, and set time to 4 minutes. Select START/PAUSE to begin.
- 5 Check pizza frequently to avoid burning the cheese. Remove when melted and browned. Repeat step 4 with remaining pizzas.
- 6 Serve pizzas warm with desired garnishes.

LOADED BAKED POTATOES

MAINS

PREP: 15 MINUTES | **COOK:** 38 MINUTES | **MAKES:** 2-4 SERVINGS

INGREDIENTS

2 russet potatoes
1/2 cup shredded cheddar cheese
1/2 can (7.5 ounces) chili
without beans
2 teaspoons kosher salt

FOR SERVING

2 tablespoons cooked
bacon bits
2 tablespoons sour cream
Fresh scallions, thinly sliced

DIRECTIONS

- 1 Pierce each potato 4 times with a fork.
- 2 Insert crisper plate in basket and place potatoes on crisper plate; insert basket in unit. Select AIR FRY, set temperature to 390°F, and set time to 35 minutes. Select START/PAUSE to begin.
- 3 After 35 minutes, remove potatoes from crisper plate. Slice them in half and spoon chili and cheese into each one. Return potatoes to crisper plate.
- 4 Select AIR FRY, set temperature to 390°F, and set time to 3 minutes. Select START/PAUSE to begin.
- 5 When cooking is complete, remove potatoes from crisper plate and top each with bacon bits, sour cream, and sliced scallions.



BEEF & BROCCOLI

PREP: 10 MINUTES | **MARINATE:** 30 MINUTES
COOK: 15 MINUTES | **MAKES:** 2-4 SERVINGS

INGREDIENTS

1 jar (12 ounces) teriyaki sauce, divided
1 tablespoon garlic powder
1/4 cup soy sauce
1 teaspoon crushed red pepper (optional)
1 pound uncooked sirloin steak, thinly sliced
1 head broccoli, cut in 1-inch florets
1 tablespoon canola oil
1 teaspoon kosher salt
1 teaspoon pepper
Cooked rice, for serving

DIRECTIONS

- 1 In a large resealable plastic bag, mix together 3/4 cup teriyaki sauce, garlic powder, soy sauce, crushed red pepper, and beef. Let marinate in the refrigerator for at least 30 minutes, or up to 24 hours.
- 2 In a large mixing bowl, toss the broccoli with canola oil, salt, and pepper.
- 3 Insert crisper plate in basket and basket in unit. Preheat unit by selecting AIR FRY, setting the temperature to 375°F, and setting the time to 3 minutes. Select START/PAUSE to begin.
- 4 After 3 minutes, place broccoli on the crisper plate; reinsert basket. Select AIR FRY, set temperature to 375°F, and set time to 15 minutes. Select START/PAUSE to begin.
- 5 After 5 minutes, remove basket from unit and move broccoli to one side of the crisper plate. Place beef on the other side. Reinsert basket to resume cooking.
- 6 Cook beef and broccoli for remaining 10 minutes, stirring once halfway through.
- 7 Cooking is complete when the beef is browned and cooked through. Add more time if needed. serve immediately with remaining teriyaki sauce and rice.



HOMEMADE FISH STICKS

MAINS

PREP: 15 MINUTES | **COOK:** 12 MINUTES | **MAKES:** 8 SERVINGS

INGREDIENTS

4 frozen tilapia fillets
(4 ounces each)
1 cup all-purpose flour
2 large eggs, beaten
1 1/2 cups seasoned bread
crumbs
1 tablespoon kosher salt

FOR SERVING

1 lemon, cut in wedges
Tartar sauce
Ketchup

DIRECTIONS

- 1 Remove tilapia from freezer. Allow to sit at room temperature for 10 minutes, then cut each fillet into 4 equal sized pieces.
- 2 Place flour in a shallow bowl. Add eggs to another bowl. Combine bread crumbs and salt in a third bowl.
- 3 Working in small batches, dredge tilapia in flour. Tap off excess, then coat in egg. Then coat evenly with bread crumbs.
- 4 Insert crisper plate in basket. Preheat unit by selecting AIR FRY, setting the temperature to 390°F, and setting the time to 3 minutes. Select START/PAUSE to begin.
- 5 After 3 minutes, place 8 fish sticks on crisper plate; insert basket in unit.
- 6 Select AIR FRY, set temperature to 390°F, and set time to 12 minutes. Select START/PAUSE to begin.
- 7 Halfway through cooking, remove basket from unit and flip fish sticks. Reinsert basket to resume cooking.
- 8 Cooking is complete when fish sticks are browned on all sides and cooked to 145°F. Remove fish sticks from crisping plate. Squeeze lemon wedges over them and serve immediately with tartar sauce or ketchup.
- 9 Repeat steps 4 through 8 with remaining fish sticks. They can also be placed in a resealable plastic bag and frozen for cooking later.

FUDGE BROWNIES

PREP: 15 MINUTES | **COOK:** 1 HOUR | **MAKES:** 6-8 SERVINGS

INGREDIENTS

1/2 cup all-purpose flour
1/4 cup unsweetened cocoa powder
3/4 teaspoon kosher salt
2 large eggs
1 tablespoon water
1/2 cup granulated sugar
1/2 cup packed dark brown sugar
1 tablespoon vanilla extract
1/2 bag (6 ounces) semisweet chocolate chips, melted
1 1/2 sticks (3/4 cup) unsalted butter, cut in pieces, melted

DIRECTIONS

- 1** In a medium bowl, whisk together flour, cocoa powder, and salt.
- 2** In a separate large bowl, whisk together eggs, water, sugars, and vanilla until smooth.
- 3** In a separate bowl, stir together melted chocolate and butter until evenly combined, then whisk into the egg mixture. Slowly add dry ingredients to the mixture, stirring just until incorporated.
- 4** Spray a 7-inch round baking pan with cooking spray and add batter to the pan.
- 5** Insert crisper plate in basket and basket in unit. Preheat unit by selecting AIR FRY, setting the temperature to 300°F, and setting the time to 3 minutes. Select START/PAUSE to begin.
- 6** After 3 minutes, place baking pan on crisper plate; reinsert basket. Select AIR FRY, set temperature to 300°F, and set time to 1 hour. Select START/PAUSE to begin.
- 7** Begin checking brownies after 45 minutes. Cooking is complete when a wooden toothpick inserted in center comes out clean. Allow brownies to cool to room temperature before removing them from the pan.



BAKED APPLES

DESSERTS

PREP: 5 MINUTES | **COOK:** 45 MINUTES | **MAKES:** 4 SERVINGS

INGREDIENTS

2 apples (Fuji, Gala, or other baking apples), cut in half, core removed, skin left on

Juice of 1 lemon

4 teaspoons light brown sugar

1/2 stick (1/4 cup) butter, cut in 16 pieces

8 teaspoons granulated sugar

TOPPINGS

Vanilla ice cream

Caramel syrup

Chopped peanuts

Crushed vanilla wafers

Crumbled graham crackers

DIRECTIONS

- 1** Pierce each apple half with a fork 6 times.
- 2** Insert crisper plate in basket and basket in unit. Preheat unit by selecting AIR FRY, setting the temperature to 325°F, and setting the time to 3 minutes. Select START/PAUSE to begin.
- 3** Place aluminum foil into the basket, over crisper plate. Place apple halves onto foil, cut-side up. Sprinkle with lemon juice and brown sugar and top each apple half with 4 pieces of butter.
- 4** Select AIR FRY, set temperature to 325°F, and set time to 45 minutes. Press START/PAUSE to begin.
- 5** After 25 minutes, remove basket from unit and sprinkle granulated sugar on top of the apples. Reinsert basket to resume cooking for another 20 minutes, or until centers of apples are softened.
- 6** When cooking is complete, serve apples with your favorite toppings.

NINJA[®]

For questions or to register your product,
visit us online at ninjakitchen.com

AF101_IG_QSG_20Recipe_REV_Mv5_211108
NINJA is a registered trademark of SharkNinja Operating LLC.
©2021 SharkNinja Operating LLC.