

GETTING STARTED

1

Scan here to download the free Ninja Pro Connect™ App.





2

Register and pair your Ninja ProChef™ Thermometer.

3

Get cooking with confidence.

THERMOMETER AND CHARGING CASE FEATURES



- A** Upper Charging Terminal
- B** Lower Charging Terminals
- C** Ambient Temp Sensor
- D** Minimum Insertion Line
Thermometer must be inserted into food up to this line to ensure a successful cook.
- E** Internal Temp Sensor
- F** Charging Case Battery LED

THERMOMETER PLACEMENT

Insert thermometer horizontally into the thickest part of the food, centering top to bottom and not at an angle.

Ensure the thermometer is not hitting any bones, fat, or gristle.

Thermometer will be less effective on cuts smaller than 1 inch.

DO NOT use the thermometer with frozen food.

If covering protein with aluminum foil, thermometer must pierce through foil, with gray head exposed to open air.

FOOD TYPE CORRECT INCORRECT

Beef Roast		
Pork Shoulder/ Butt		
Whole Fish		
Fish Fillet		
Pork Loin		
Steak		
Poultry Breast		
Whole Poultry		


IMPORTANT: If using a second thermometer from a different brand, temperature may vary between the two. This could be due to the location of the secondary thermometer in food, temperature variance within food, and/or the secondary thermometer's potential for inaccuracy.

BATTERY INSTALLATION

Remove plastic wrap from battery.

Open battery cover with a coin.

Insert battery with + symbol facing out.



CLEANING INSTRUCTIONS

NOTE: DO NOT submerge thermometer in water when hot. Doing so may cause damage to the thermometer and risk malfunction. Allow to fully cool before washing.

Wash thermometer with warm, soapy water and a soft cloth or sponge. Allow it to dry completely. Ensure thermometer is totally clean before installing in charging case.

Do not place the charging case under water. If necessary, wipe it with a damp cloth.

NINJA PROCHEF™ WIRELESS THERMOMETER



SCAN HERE to download the Ninja Pro Connect™ App

REGISTER YOUR PURCHASE

registeryourninja.com

Scan QR code using mobile device



RECORD THIS INFORMATION

Model Number: _____

Serial Number: _____

Date of Purchase: _____

(Keep receipt)

Store of Purchase: _____

NINJA is a registered trademark of SharkNinja Operating LLC.

NINJA PROCHEF and NINJA PRO CONNECT are trademarks SharkNinja Operating LLC.


© 2024 SharkNinja Operating LLC, Needham, MA 02494.

WP100_IBQSG_REV_Mv21_240815

CHARGING CASE PLACEMENT WHILE COOKING

Keep charging case as close as possible to cooking appliance and thermometer to ensure a strong signal.

NOTE: Charging case maintains a strong connection with your phone—up to 165 feet in open air with a direct, unobstructed line of sight between the two devices. Obstacles such as garages, doors, and walls (particularly when entering the house with your phone while cooking food outside) may disrupt the connection.



NOTE: DO NOT place the charging case on any hot surfaces.

DONENESS CHART

RARE	120°F–125°F
MED RARE	130°F–135°F
MED	140°F–145°F
MED WELL	150°F–155°F
WELL	160°F–165°F

THE IMPORTANCE OF RESTING MEAT

Did you know that meat continues to cook, even after you remove it from heat?

To prevent overcooking, the thermometer will automatically ask you to remove your food from the heat source so it can rest and reach the perfect doneness level.

Skipping or ignoring the rest period and cutting into food immediately may result in a rarer level of doneness.

AMBIENT SENSOR

The ambient sensor on the thermometer detects the air temperature surrounding food, not the entire appliance. This reading may not always match the temperature set on the appliance.

IMPORTANT SAFETY INSTRUCTIONS FOR HOUSEHOLD USE ONLY. READ ALL INSTRUCTIONS BEFORE USE.

Failure to follow these instructions could result in serious bodily injury or damage to property.

- **WARNING.** Do not use appliance for other than intended use.
- To eliminate a choking hazard for young children, discard all packaging materials immediately upon unpacking.
- **ONLY** for use with food.
- Burn and scald hazard. **DO NOT** touch hot thermometer with bare hands. Ensure you wear heat-resistant gloves when removing the thermometer from cooked food.
- Thermometer is sharp! Care shall be taken when handling and used near children and certain persons with disabilities.
- This is not a toy. **DO NOT** allow children to use and play with thermometer.
- Do not place the thermometer under running water immediately after cooking. Allow it to cool down first.
- **DO NOT** use the thermometer in a microwave oven or pressure cooker. Damage may occur to thermometer or cooking apparatus.
- **DO NOT** place the thermometer and charging dock on any hot surface such as a stovetop or electric burner, or in a heated oven.

BATTERY SAFETY

- Place battery into charging case in proper polarity (+ and -).
- Remove battery during long periods of non-use to prevent leakage.
- Properly dispose of used battery. **DO NOT** dispose of battery in fire.
- **DO NOT** expose charging case to rain or moisture.

USE AND CARE

- Make sure the thermometer is fully inserted, exceeding the minimum insertion line. Damage to thermometer may occur if not fully inserted.
- Thermometer should be placed in the thickest part of the food, away from bone, fat, or gristle.
- **DO NOT** cover or wrap the thermometer in aluminum foil. Loss of Bluetooth connection is possible if covered. Poke the thermometer through the foil to maintain connection.
- To prevent bacterial contamination, always wash hands after inserting thermometer into raw non-vegetarian/agrarian foods.
- **DO NOT** place the thermometer or charging case in the dishwasher. Hand-wash only.
- Clean thermometer with warm, soapy water, then rinse and dry.

- **DO NOT** use scouring pads or abrasive cleaners, as they will damage the thermometer.
- When not in use, store the thermometer and charging case in a cool, dry place. Be sure thermometer is dry before storing.

FCC WARNING

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

These limits are designed to provide reasonable protection against harmful interference in a residential installation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help. Radiation Exposure Statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

SAVE THESE INSTRUCTIONS.

Shark NINJA

ONE (1) YEAR LIMITED WARRANTY

NJA_1_YR_IB_LMTD_WRNTY-2-Column_US_ENG

The One (1) Year Limited Warranty applies to purchases made from authorized retailers of **SharkNinja Operating LLC**. Warranty coverage applies to the original owner and to the original product only and is not transferable.

SharkNinja warrants that the unit shall be free from defects in material and workmanship for a period of one (1) year from the date of purchase when it is used under normal household conditions and maintained according to the requirements outlined in the Owner's Guide, subject to the following conditions and exclusions:

What is covered by this warranty?

1. The original unit and/or non-wearable parts deemed defective, in SharkNinja's sole discretion, will be repaired or replaced up to one (1) year from the original purchase date.
2. In the event a replacement unit is issued, the warranty coverage ends six (6) months following the receipt date of the replacement unit or the remainder of the existing warranty, whichever is later. SharkNinja reserves the right to replace the unit with one of equal or greater value.

What is not covered by this warranty?

1. Normal wear and tear of wearable parts (such as blending vessels, lids, cups, blades, blender bases, removable pots, racks, pans, etc.), which require regular maintenance and/or replacement to ensure the proper functioning of your unit, are not covered by this warranty. Replacement parts are available for purchase at ninjaccessories.com.
2. Any unit that has been tampered with or used for commercial purposes.
3. Damage caused by misuse, abuse, negligent handling, failure to perform required maintenance (e.g., failure to keep the well of the motor base clear of food spills and other debris), or damage due to mishandling in transit.
4. Consequential and incidental damages.

5. Defects caused by repair persons not authorized by SharkNinja. These defects include damages caused in the process of shipping, altering, or repairing the SharkNinja product (or any of its parts) when the repair is performed by a repair person not authorized by SharkNinja.

6. Products purchased, used, or operated outside North America.

How to get service

If your appliance fails to operate properly while in use under normal household conditions within the warranty period, visit ninjakitchen.com/support for product care and maintenance self-help. Our Customer Service Specialists are also available at **1-877-646-5288** to assist with product support and warranty service options, including the possibility of upgrading to our VIP warranty service options for select product categories. So we may better assist you, please register your product online at registryourninja.com and have the product on hand when you call.

SharkNinja will cover the cost for the customer to send in the unit to us for repair or replacement. A fee of \$20.95 (subject to change) will be charged when SharkNinja ships the repaired or replacement unit.

How to initiate a warranty claim

You must call **1-877-646-5288** to initiate a warranty claim. You will need the receipt as proof of purchase. We also ask that you register your product online at registryourninja.com and have the product on hand when you call, so we may better assist you. A Customer Service Specialist will provide you with return and packing instruction information.

How state law applies

This warranty gives you specific legal rights, and you also may have other rights that vary from state to state. Some states do not permit the exclusion or limitation of incidental or consequential damages, so the above may not apply to you.