

Please make sure to read the enclosed safety instructions prior to using your unit.



NINJA SLUSHi™

PROFESSIONAL FROZEN DRINK MAKER

10+ DELICIOUS RECIPES
INSPIRATION GUIDE



NO ICE, NO BLENDING, FULL FLAVOR.

Welcome to the Ninja Slushi™ Professional Frozen Drink Maker with RapidChill Technology. From here, you're just a few pages away from recipes, tips, tricks, and helpful hints to give you the confidence to make almost anything into the perfect slushy treat in 60 minutes or less. Now let's make some frozen drinks in the comfort of your own home!



For helpful tips and tricks on how to use your Ninja Slushi™, scan the QR code.

TABLE OF CONTENTS

USING THE CONTROL PANEL	2
RAPIDCHILL TECHNOLOGY	3
PRESETS	4
WHAT'S IN THE BOX	5
ASSEMBLY	6
USING THE NINJA SLUSHI™	7
USING THE RINSE CYCLE	8
DISASSEMBLY & CLEANING	9
REQUIRED SUGAR CONTENT	10
ALCOHOL GUIDELINES	11
TIPS & TRICKS	12
NO-PREP SLUSHES	13
FROZEN COCKTAIL HOUR	14
TROPICAL RECIPE INSPIRATIONS	15
KICKSTARTERS	16
RECIPES	24

USING THE CONTROL PANEL

POWER

Press to turn the unit on and off.

RINSE CYCLE

This cycle agitates, without cooling, to rinse the unit.

PRESETS

5 unique presets that use RapidChill Technology to determine the perfect temperature for the ideal frozen drink.

TEMPERATURE CONTROL SETTING

Each preset will start at a default/optimal temperature for ideal texture. If desired, adjust the temperature for your perfect frozen drink texture.

For sippable frozen drinks, decrease the temperature level by pressing the bottom arrow on the control panel.

For thicker, colder frozen drinks, increase the temperature level by pressing the top arrow on the control panel.

TROUBLESHOOTING TIPS

RECIPE NOT SLUSHING? If your recipe has not reached the desired texture after 60 minutes, increase the temperature one level. Wait 10-15 minutes to test the recipe. If the texture still isn't what you desire, increase temperature by one level again. Repeat until desired texture is achieved.

SLUSH NOT DISPENSING? For the best dispensing experience, fill the unit to the max fill line and ensure the unit is running. For a smoother dispense experience, decrease the temperature level by pressing the bottom arrow on the control panel. More sippable frozen drinks will dispense smoother.

Refer to pages 10-11 for more troubleshooting tips.



NOTE: Colors, components, and functions may vary by model.

RAPID CHILL TECHNOLOGY

No ice, no blending, full flavor.

Create more flavorful, less-watered down frozen drinks at home.*



Frozen drinks in 60 minutes** or less.

Once frozen drink reaches desired temperature, unit will beep. Auger will continue running to mix your drinks and keep them ready for dispensing at any time.



Up to 12 hours† of runtime for frozen drinks on tap.

The unit will continue running to keep your drinks at the ideal temperature, prevent them from freezing solid, and be ready to dispense when your craving hits.††

Top off your recipe for neverending frozen drinks for your party needs. Simply add more liquid to the vessel while the unit is running.



* Vs. BN800.

** Creating drinks can take up to 15-60 minutes depending on ingredients, volume, and starting temperature.

† For recipes excluding dairy.

†† To avoid a foamy output when using the Milkshake or Frappé preset, add 24 oz or more of desired drink, and dispense contents within 30 minutes of the preset ending.


PRESETS

5 unique presets use RapidChill Technology for the perfect temperature for your ideal frozen drink.


PRESET	DEFAULT/OPTIMAL TEMPERATURE	DESIGNED FOR
SLUSH		Transforming your everyday beverages
SPIKED SLUSH		Beverages with alcohol content
FRAPPÉ		Coffee shop lovers to make frozen treats
MILKSHAKE		Dairy- and creamier-based beverages
FROZEN JUICE		Naturally sweetened beverages

Each preset will start at a default/optimal temperature for ideal texture. If desired, adjust the temperature level for your perfect frozen drink texture.

5 PRESET SETTINGS




TEMPERATURE CONTROL



WHAT'S IN THE BOX

NOTE: Colors, components, and functions may vary by model.



2-PART DRIP TRAY
Store drip tray on side of unit by sliding it onto the knob.

*16-oz minimum liquid capacity.
64-oz maximum liquid capacity.

ASSEMBLY

Keep unit upright for at least 2 hours before first use.



1. Ensure all parts are fully cleaned and the motor base is level on a flat, solid surface.



2. Install the condensation catch under the evaporator by sliding it into the rail grooves.



3. Install the auger by sliding it over the evaporator until it fits into place on the pin.



4. With the bail handle up, slide the vessel over the auger and evaporator.



5. Lock the vessel into place by pushing the bail handle back to seal the vessel.



6. Insert the drip tray in front of the motor base until it clicks into place.

USING THE NINJA SLUSHI™

Minimum input = 2 cups (16 oz) Maximum input = 8 cups (64 oz)



- 1.** Plug in the unit.
- 2.** Open the cover on the top of the vessel.
- 3.** Add liquid(s) through the easy-fill port and close the cover.
- 4.** Press the power button to turn on the unit.



- 5.** Choose your desired preset. The preset will start at the default/optimal temperature. If desired, adjust temperature for your perfect frozen drink texture.
- 6.** Temperature Control LEDs pulse showing progress to reach your selected temperature. **Unit will beep and LEDs will remain solid once frozen drink reaches temperature.**



- 7.** Place a cup on the drip tray, under the handle.
- 8.** To dispense, slowly pull the handle. To stop, release the handle back into place.

NOTE:

- Stopping the unit also stops the auger and cooling process. You will need to keep the unit running to dispense contents.
- Temperature Control Setting LEDs will pulse while frozen drink is freezing to your set temperature level. Once frozen drink reaches the desired temperature, LEDs will remain solid and unit will beep. Unit will continue running to keep your frozen drink at the ideal temperature and be ready to dispense.
- Creating drinks can take up to 15-60 minutes depending on ingredients, volume, and starting temperature.
- Pre-frozen ingredients taste sweeter. Worried your drink might be too sweet? Don't worry, it won't taste as sweet after you freeze and slush it into a frozen drink.

USING THE RINSE CYCLE

This cycle agitates, without cooling, to rinse the unit. After using the Rinse cycle, wash all parts by hand or in a dishwasher to fully clean the unit after each use.

1. Dispense any remaining frozen drink.
2. Stop the current preset. Press the RINSE button.
3. Add hot water up to the vessel's max fill line (64 oz).
4. Slowly dispense the water from the unit immediately after filling.

NOTE: This water will dispense quickly. Ensure you use a large cup or bowl to capture it.

5. Stop Rinse cycle by pressing the RINSE button again.
6. Press the power button to turn off the unit.

NOTE: If needed, repeat until frozen drink is rinsed off the evaporator.



See the next page for more details on cleaning parts after using the Rinse cycle.

DISASSEMBLY & CLEANING

All parts, except the motor base and evaporator, are bottom-rack dishwasher safe, and should NOT be cleaned with a heated dry cycle.

For best results, use the Rinse cycle before disassembling and cleaning all parts.



1. Unlock the bail handle by pulling forward and remove the vessel by gently pulling it off the unit. Ensure the vessel is tipped down to prevent remaining liquid from spilling out the back of the vessel. Set aside.



2. Slide the auger off the evaporator. Set aside.



3. Wipe down the evaporator with a sanitized or warm, damp cloth.



4. Gently slide the condensation catch out of the unit, since there may be residual liquid in the condensation catch. Set aside.



5. Wipe down unit underneath the evaporator with a sanitized or warm, damp cloth.
6. If needed, remove the drip tray and/or spout shroud.



7. Hand-wash all parts in hot, soapy water, or use a dishwasher. If needed, repeat until all parts are fully clean.

8. Wipe down the motor base and evaporator with a sanitized or warm, damp cloth.
9. Allow all parts to dry thoroughly before reassembling and/or storing the unit.

REQUIRED SUGAR CONTENT

All inputs must contain at least 4% sugar.

SUGAR GUIDELINES

Refer to drink/liquid nutrition label to ensure sugar content meets the recommended minimums below:

LISTED SERVING SIZE	MINIMUM TOTAL SUGAR AMOUNT
8 oz (240 ml)	8 g
12 oz (355 ml)	11 g
20 oz (591 ml)	18 g

EXAMPLE: Apple juice

Nutrition Facts	
8 Servings per container	
Serving size 8 fl oz (240 ml)	Serving Size
Amount per serving	
Calories 120	
% Daily Value*	
Total Fat 0g	0%
Sodium 25mg	1%
Total Sugars 26g	11%
Potassium 251mg	6%
Vitamin C 108mg	120%

Not a significant source of saturated fat, trans fat, cholesterol, dietary fiber, added sugars, vitamin D, calcium and iron.
*The % Daily Value (DV) tells you how much a nutrient in a serving of food contributes to a daily diet. 2,000 calories a day is used for general nutrition advice.

Serving Size

Total Sugars (26 g meets the minimum requirements)



! TROUBLESHOOTING TIPS

Low-sugar alert: Temperature Control LEDs will flash one at a time in **descending order** starting with the top LED, preset LEDs will flash, and the unit will beep every minute for 15 minutes.

If a drink does not meet minimum requirement of total sugar: Add 1-2 tablespoons flavored syrup, juice, sugar, date sugar, coconut sugar, maple syrup, agave, simple syrup, or honey per serving. Combine additional sugar with the base prior to pouring into unit. Reset the unit by pressing the preset. Restart by pressing the preset again.

NOTE: Sugar-free substitutes or artificial sweeteners will not aid in meeting total minimum or maximum sugar requirements.

SUGAR PERCENTAGES

DIET SODA



SUGAR % below this point will freeze too hard to create slush

LOW LIMIT 4%

FRUIT JUICE



SPORTS DRINK



FRAPPÉ



SODA



ALCOHOL GUIDELINES

The perfect balance for your favorite frozen cocktails at home.

When using the Spiked Slush preset, all premade inputs (wine, beer, etc.) must contain between 2.8% and 16% alcohol.

HARD ALCOHOL/SPIRIT GUIDELINES

To create frozen cocktails, see chart below for the maximum hard alcohol/spirit (vodka, tequila, etc.) content per total recipe size.


TOTAL RECIPE SIZE	MAXIMUM ALCOHOL AMOUNT
3 cups (24 oz)	1/2 cup (4 oz)
4 1/2 cups (36 oz)	3/4 cup (6 oz)
6 cups (48 oz)	1 cup (8 oz)
8 cups (64 oz)	1 1/4 cup (10 oz)

Chart above is a guide for incorporating hard alcohol/spirits (35%+) **ONLY**. When using other alcohols such as wine, beer, seltzer, or premade cocktails, refer to the chart below or the No-Prep Slushes guide on page 13.

! TROUBLESHOOTING TIPS

High-alcohol/high-sugar alert: Temperature Control LEDs will flash one at a time in **ascending order** starting with the bottom LED, preset LEDs will flash, and the unit will beep every minute for 15 minutes.

If a drink exceeds the maximum alcohol and sugar amount: Add 1/4 cup water, soda, tonic water, seltzer, or coffee/tea per serving to dilute the input. Reset the unit by pressing the preset. Restart by pressing the preset again.



ALCOHOL PERCENTAGES

LIGHT BEER



HARD SELTZER



IPA



WINE



MARGARITA



TO CREATE SLUSH alcohol level must be below (or diluted to) this limit

MARTINI



LOW LIMIT 2.8%

HIGH LIMIT 16%

TIPS & TRICKS

Minimum input = 2 cups (16 oz) Maximum input = 8 cups (64 oz)

For the best dispensing experience, fill the unit to the max-fill line (64 oz).



DO NOT add hot ingredients, ice, or solid ingredients like fruit, ice cream, or frozen fruit.



All inputs must contain at least 4% sugar.*



When using the **SPIKED SLUSH** program, all premade inputs must contain between **2.8% and 16% alcohol****.



For best results, chill liquid(s) before adding to the unit.



For your ideal texture, use the Temperature Control setting to adjust.



For the frostiest results, chill serving glasses before dispensing your Slushi creations.

NOTE: Pre-frozen ingredients taste sweeter. Worried your drink might be too sweet? Don't worry, it won't taste as sweet after you freeze and slush it into a frozen drink.

*Refer to page 10 for more details. **Refer to page 11 for more details.

POUR & SLUSH

NO-PREP SLUSHES

SIMPLY FILL & SELECT

Add 2-8 cups (16-64 oz) to the unit, then select desired preset.



PRESET	PREPARED DRINK	DIRECTIONS
SLUSH TOTAL TIME: 2-3 SERVINGS 15 MINUTES 4-6 SERVINGS 30 MINUTES 6-8 SERVINGS 45 MINUTES	Sports drinks, energy drinks, sweetened iced tea, kombucha, lemonade, limeade	Select SLUSH . The preset will start at the default level—adjust temperature control to illuminate 1 bar.
	Soda, fruit punch	Select SLUSH . The preset will start at the default level—adjust temperature control to illuminate 3 bars.
SPIKED SLUSH TOTAL TIME: 2-3 SERVINGS 30 MINUTES 4-6 SERVINGS 40 MINUTES 6-8 SERVINGS 50 MINUTES	Hard seltzers	Select SPIKED SLUSH . The preset will start at the default level—adjust temperature control to illuminate 3 bars.
	Sour beers, hard tea, hard cider	Select SPIKED SLUSH . The preset will start at the default level—adjust temperature control to illuminate 5 bars.
	Hard kombucha, hard lemonade, Paloma, Moscow Mule	Select SPIKED SLUSH . The preset will start at the default level—adjust temperature control to illuminate 6 bars.
	Rum & Cola, wine (white or rosé)	Select SPIKED SLUSH . The preset will start at the default level—adjust temperature control to illuminate 9 bars.
	Premixed margaritas	Select SPIKED SLUSH . The preset will start at the default level—adjust temperature control to illuminate 10 bars.
FROZEN JUICE TOTAL TIME: 2-3 SERVINGS 15 MINUTES 4-6 SERVINGS 25 MINUTES 6-8 SERVINGS 35 MINUTES	Cranberry juice, orange juice, mango juice, watermelon juice, tropical juice	Select FROZEN JUICE . The preset will start at the default level—adjust temperature control to illuminate 1 bar.
	Apple juice/apple cider	Select FROZEN JUICE . The preset will start at the default level—adjust temperature control to illuminate 2 bars
	Bottled premade smoothies, pineapple juice	Select FROZEN JUICE . The preset will start at the default level—adjust temperature control to illuminate 3 bars
	Grape juice, cherry juice	Select FROZEN JUICE . The preset will start at the default level—adjust temperature control to illuminate 5 bars

Refer to page 36 for the Create Your Own Milkshake & Frappé chart.

FROZEN COCKTAIL HOUR

Use the steps below to mix and match ingredients to be the ultimate staycation bartender.
For steps 1-3, use the table for recipe quantities.

TOTAL TIME: 2-3 SERVINGS: 30 MINUTES | 4-6 SERVINGS: 40 MINUTES | 6-8 SERVINGS: 50 MINUTES

1. **Pick a drink mix**
Choose a base for your cocktail.

2. **Add water**
3. **Add alcohol**

4. **Select SPIKED SLUSH**
The preset will start at the default/optimal setting. If desired, adjust the temperature for your perfect frozen drink texture.
5. **Dispense. Garnish if desired, and enjoy.**


	2-3 SERVINGS	4-6 SERVINGS	6-8 SERVINGS
1. DRINK MIX Strawberry daquiri mix Piña colada mix Margarita mix Cosmopolitan mix Mai tai mix	add 1 2/3 cups drink mix	add 2 1/4 cups drink mix	add 3 1/4 cups drink mix
2. WATER	add 1 cup + 2 tablespoons water	add 1 2/3 cups water	add 2 1/4 cups water
3. ALCOHOL White rum Dark rum Vodka Tequila Gin	add 1/4 cup alcohol	add 1/3 cup alcohol	add 1/2 cup alcohol

NOTE:

- Mixes should not contain alcohol. Refer to Required Sugar Content on page 10.
- Refer to Alcohol Guidelines on page 11 for more information on alcohol amounts per recipe size.
- When using LIGHT or LOWER SUGAR drink mixes, omit water from recipe and replace with additional light drink mix in the equal amount.

TROPICAL RECIPE INSPIRATIONS



STRAWBERRY DAQUIRI

1. Strawberry daquiri mix
2. Water
3. White rum
4. Select **SPIKED SLUSH**
5. Garnish with strawberry & lime



FROZEN MAITAI

1. Mai tai drink mix
2. Water
3. White & dark rum
4. Select **SPIKED SLUSH**
5. Garnish with lime wedges & cherries

NOTE: Cocktails made with prepared concentrated drink mixes are best enjoyed diluted with ice. We include water in our recipes and charts to ensure the best flavors and textures of your frozen drinks.

KID FRIENDLY

ONE-INGREDIENT SODA SLUSH

KICKSTARTER

TOTAL TIME: 2-3 SERVINGS: 15 MINUTES | 4-6 SERVINGS: 40 MINUTES | 6-8 SERVINGS: 45 MINUTES

INGREDIENTS

2-3 SERVINGS	4-6 SERVINGS	6-8 SERVINGS
2 (12-oz) cans (or 3 cups) soda	4 (12-oz) cans (or 6 cups) soda	5 (12-oz) cans (or 7 1/2 cups) soda



USE ANY OF THE FOLLOWING SODAS:

Cola, orange, lemon-lime, cream, root beer, ginger ale, grape, or any generic soda.

DIRECTIONS



Pour soda into the vessel.



Select **SLUSH**. Preset will start at the default/optimal temperature for ideal texture. If desired, adjust temperature.



Once frozen drink reaches optimal temperature, unit will beep. Serve immediately.

TEMPERATURE PROGRESS:


Temperature Control LEDs pulse showing progress to reach your selected temperature. Unit will beep and LEDs will remain solid once frozen drink reaches temperature.

TIP: For best results, chill liquid before adding to the unit.

NOTE:

- Diet soda (or soda made with artificial sugar substitutes) will **NOT** work in this unit.
- For easier cleaning, **DO NOT** turn off preset until all frozen drink has been dispensed.

SLUSH



FROZEN MIMOSA

KICKSTARTER

TOTAL TIME: 2-3 SERVINGS: 30 MINUTES | 4-6 SERVINGS: 45 MINUTES | 6-8 SERVINGS: 60 MINUTES

INGREDIENTS

2-3 SERVINGS	4-6 SERVINGS	6-8 SERVINGS
1 1/4 cups orange juice	2 1/2 cups orange juice	3 1/3 cups orange juice
1 3/4 cups sparkling wine, Champagne, Prosecco, or Cava	3 1/2 cups sparkling wine, Champagne, Prosecco, or Cava	4 2/3 cups sparkling wine, Champagne, Prosecco, or Cava

DIRECTIONS

Prior to starting recipe, refer to pages 6 and 7 for assembly and use information.



Pour all ingredients into the vessel.



Select **SPIKED SLUSH**. Preset will start at the default/optimal temperature for ideal texture. If desired, adjust temperature.



Once frozen drink reaches optimal temperature, unit will beep. Serve immediately.

TEMPERATURE PROGRESS:

Temperature Control LEDs pulse showing progress to reach your selected temperature. Unit will beep and LEDs will remain solid once frozen drink reaches temperature.



MAKE IT A MOCKTAIL:

Swap out the champagne for sparkling white grape juice or sparkling cider and run on the SLUSH program. The preset will start at the default level—adjust temperature control to illuminate 8 bars.

TIP: For best results, chill liquid before adding to the unit.

NOTE: For easier cleaning, **DO NOT** turn off preset until all frozen drink has been dispensed.



KID FRIENDLY

TROPICAL JUICE SLUSH

KICKSTARTER

TOTAL TIME: 2-3 SERVINGS: 15 MINUTES | 4-6 SERVINGS: 25 MINUTES | 6-8 SERVINGS: 35 MINUTES

INGREDIENTS

2-3 SERVINGS	4-6 SERVINGS	6-8 SERVINGS
3 cups tropical juice blend	6 cups tropical juice blend	7 1/2 cups tropical juice blend

DIRECTIONS

Prior to starting recipe, refer to pages 6 and 7 for assembly and use information.



Pour tropical juice blend into the vessel.



Select **FROZEN JUICE**. Preset will start at the default/optimal temperature for ideal texture. If desired, adjust temperature.



Once frozen drink reaches optimal temperature, unit will beep. Serve immediately.

TEMPERATURE PROGRESS:

Temperature Control LEDs pulse showing progress to reach your selected temperature. Unit will beep and LEDs will remain solid once frozen drink reaches temperature.

TIP: For best results, chill liquid before adding to the unit.

NOTE: For easier cleaning, **DO NOT** turn off preset until all frozen drink has been dispensed.

FROZEN JUICE



KID FRIENDLY

CHOCOLATE MILKSHAKE

KICKSTARTER

PREP: 5 MINUTES

TOTAL TIME: 2-3 SERVINGS: 25 MINUTES
4-6 SERVINGS: 30 MINUTES
6-8 SERVINGS: 50 MINUTES



MAKE IT DAIRY FREE:

Swap out dairy ingredients for dairy-free alternatives if desired.

TIP: When using the **Milkshake** or **Frappé** preset, dispense contents within 30 minutes of the preset ending to avoid a foamy output.

NOTE: For easier cleaning, **DO NOT** turn off preset until all frozen drink has been dispensed.

TEMPERATURE PROGRESS:

Temperature Control LEDs pulse showing progress to reach your selected temperature. Unit will beep and LEDs will remain solid once frozen drink reaches temperature.

INGREDIENTS


2-3 SERVINGS	4-6 SERVINGS	6-8 SERVINGS
2 cups whole milk	4 cups whole milk	4 1/3 cups whole milk
1 cup heavy cream	2 cups heavy cream	2 1/3 cups heavy cream
1 teaspoon vanilla extract	2 teaspoons vanilla extract	1 tablespoon vanilla extract
2 tablespoons granulated sugar	1/4 cup granulated sugar	1/3 cup granulated sugar
1/4 cup chocolate syrup	1/2 cup chocolate syrup	2/3 cup chocolate syrup
2 tablespoons cocoa powder	1/4 cup cocoa powder	1/2 cup cocoa powder

TOPPINGS (optional)

Whipped cream
Chocolate sauce

DIRECTIONS

Prior to starting recipe, refer to pages 6 and 7 for assembly and use information.



In a pitcher or large bowl, whisk together all ingredients until combined and sugar, chocolate syrup, and cocoa powder are fully dissolved. Pour mixture into the vessel.



Select **MILKSHAKE**. Preset will start at the default/optimal temperature for ideal texture. If desired, adjust temperature.



Once frozen drink reaches optimal temperature, unit will beep. Serve immediately, topped with whipped cream and chocolate sauce as desired.

KID FRIENDLY

CRANBERRY LIME SLUSH

TOTAL TIME: 2-3 SERVINGS: 10 MINUTES | 4-6 SERVINGS: 20 MINUTES | 6-8 SERVINGS: 30 MINUTES

INGREDIENTS

2-3 SERVINGS	4-6 SERVINGS	6-8 SERVINGS
2 1/3 cups cranberry juice	4 1/3 cups cranberry juice	5 3/4 cups cranberry juice
2/3 cups limeade	1 1/3 cups limeade	1 1/2 cups limeade

DIRECTIONS

Prior to starting recipe, refer to pages 6 and 7 for assembly and unit interaction information.

1. Pour all ingredients into the vessel.
2. Select **FROZEN JUICE**. Preset will start at the default/optimal temperature for ideal texture. If desired, adjust temperature.
3. Once frozen drink reaches optimal temperature, unit will beep. Serve immediately.

TIP: For best results, chill liquid before adding to the unit.

NOTE: For easier cleaning, **DO NOT** turn off preset until all frozen drink has been dispensed.

TEMPERATURE PROGRESS: Temperature Control LEDs pulse showing progress to reach your selected temperature. Unit will beep and LEDs will remain solid once frozen drink reaches temperature.

FROZEN JUICE

KID FRIENDLY

VANILLA MILKSHAKE

PREP: 5 MINUTES
TOTAL TIME: 2-3 SERVINGS: 20 MINUTES | 4-6 SERVINGS: 30 MINUTES | 6-8 SERVINGS: 35 MINUTES

INGREDIENTS

2-3 SERVINGS	4-6 SERVINGS	6-8 SERVINGS
2 1/2 cups whole milk	5 cups whole milk	5 3/4 cups whole milk
1/2 cup heavy cream	1 cup heavy cream	1 cup plus 2 tablespoons heavy cream
1/2 cup granulated sugar	1 cup granulated sugar	1 1/4 cups granulated sugar
1 tablespoon vanilla extract	2 tablespoons vanilla extract	2 1/2 tablespoons vanilla extract

TOPPING (optional)

Whipped cream

DIRECTIONS

Prior to starting recipe, refer to pages 6 and 7 for assembly and unit interaction information.

1. In a pitcher or large bowl, whisk together all ingredients until combined and sugar is fully dissolved. Pour mixture into the vessel.
2. Select **MILKSHAKE**. Preset will start at the default/optimal temperature for ideal texture. If desired, adjust temperature.
3. Once frozen drink reaches optimal temperature, unit will beep. Serve immediately, topped with whipped cream as desired.

TIP: When using the Milkshake or Frappé preset, dispense contents within 30 minutes of the preset ending to avoid a foamy output.

TEMPERATURE PROGRESS: Temperature Control LEDs pulse showing progress to reach your selected temperature. Unit will beep and LEDs will remain solid once frozen drink reaches temperature.



MAKE IT DAIRY FREE:

Swap out dairy ingredients for dairy-free alternatives if desired.

NOTE: For easier cleaning, **DO NOT** turn off preset until all frozen drink has been dispensed.

PINK LEMONADE SLUSH

PREP: 5 MINUTES
TOTAL TIME: 2-3 SERVINGS: 15 MINUTES | 4-6 SERVINGS: 30 MINUTES | 6-8 SERVINGS: 45 MINUTES

INGREDIENTS

2-3 SERVINGS	4-6 SERVINGS	6-8 SERVINGS
2 ³ / ₄ cups water 1/3 cup + 2 teaspoons pink lemonade powder mix	5 ¹ / ₂ cups water ² / ₃ cup + 4 teaspoons pink lemonade powder mix	7 ¹ / ₃ cups water ³ / ₄ cup + 2 tablespoons pink lemonade powder mix

DIRECTIONS

Prior to starting recipe, refer to pages 6 and 7 for assembly and unit interaction information.

1. In a pitcher or large bowl, whisk together all ingredients until combined and lemonade powder is fully dissolved.
2. Pour mixture into the vessel.
3. Select **SLUSH**. Preset will start at the default/optimal temperature for ideal texture. If desired, adjust temperature.
4. Once frozen drink reaches optimal temperature, unit will beep. Serve immediately.

NOTE: For easier cleaning, **DO NOT** turn off preset until all frozen drink has been dispensed.

TEMPERATURE PROGRESS: Temperature Control LEDs pulse showing progress to reach your selected temperature. Unit will beep and LEDs will remain solid once frozen drink reaches temperature.

SLUSH

COCONUT LIME DAIQUIRI

PREP: 5 MINUTES
TOTAL TIME: 2-3 SERVINGS: 40 MINUTES | 4-6 SERVINGS: 45 MINUTES | 6-8 SERVINGS: 55 MINUTES

INGREDIENTS

2-3 SERVINGS	4-6 SERVINGS	6-8 SERVINGS
1 ¹ / ₄ cups unsweetened canned coconut milk 1 ¹ / ₄ cups limeade ¹ / ₄ cup + 2 tablespoons light rum Juice of 2 limes 3 tablespoons granulated sugar	2 ¹ / ₂ cups unsweetened canned coconut milk 2 ¹ / ₂ cups limeade ³ / ₄ cup light rum Juice of 3 limes ¹ / ₄ cup granulated sugar	3 ¹ / ₃ cups unsweetened canned coconut milk 3 ¹ / ₃ cups limeade 1 cup light rum Juice of 4 limes ¹ / ₃ cup granulated sugar

DIRECTIONS

Prior to starting recipe, refer to pages 6 and 7 for assembly and unit interaction information.

1. In a pitcher or large bowl, whisk together all ingredients until coconut milk is emulsified and smooth.
2. Pour mixture into the vessel.
3. Select **SPIKED SLUSH**. Preset will start at the default/optimal temperature for ideal texture. If desired, adjust temperature.
4. Once frozen drink reaches optimal temperature, unit will beep. Serve immediately.

NOTE: For easier cleaning, **DO NOT** turn off preset until all frozen drink has been dispensed.

TEMPERATURE PROGRESS: Temperature Control LEDs pulse showing progress to reach your selected temperature. Unit will beep and LEDs will remain solid once frozen drink reaches temperature.



MAKE IT A MOCKTAIL:

Swap out the rum for zero-proof light rum and run on the **SLUSH** program. The preset will start at the default level.

CARAMEL FRAPPÉ

FRAPPÉ

PREP: 5 MINUTES
TOTAL TIME: 2-3 SERVINGS: 15 MINUTES | 4-6 SERVINGS: 25 MINUTES | 6-8 SERVINGS: 50 MINUTES

INGREDIENTS

2-3 SERVINGS	4-6 SERVINGS	6-8 SERVINGS
1 cup half & half	1 1/2 cups half & half	2 1/4 cups half & half
2 cups black coffee	3 cups black coffee	4 1/2 cups black coffee
1/3 cup caramel sauce	1/2 cup caramel sauce	3/4 cup caramel sauce

TOPPINGS (optional)

Whipped cream
 Caramel sauce

DIRECTIONS

Prior to starting recipe, refer to pages 6 and 7 for assembly and unit interaction information.

1. In a pitcher or large bowl, whisk together all ingredients until combined and caramel sauce is fully dissolved.
2. Pour mixture into the vessel.
3. Select **FRAPPÉ**. Preset will start at the default/optimal temperature for ideal texture. If desired, adjust temperature.
4. Once frozen drink reaches optimal temperature, unit will beep. Serve immediately, topped with whipped cream and caramel sauce as desired.

TIP: To create a mocha frappé, swap out the caramel sauce for chocolate sauce.

TIP: When using the Milkshake or Frappé preset, dispense contents within 30 minutes of the preset ending to avoid a foamy output.

TEMPERATURE PROGRESS: Temperature Control LEDs pulse showing progress to reach your selected temperature. Unit will beep and LEDs will remain solid once frozen drink reaches temperature.



MAKE IT DAIRY FREE:

Swap out dairy ingredients for dairy-free alternatives if desired.

NOTE: For easier cleaning, **DO NOT** turn off preset until all frozen drink has been dispensed.

COFFEE FRAPPÉ

FRAPPÉ

PREP: 5 MINUTES
TOTAL TIME: 2-3 SERVINGS: 15 MINUTES | 4-6 SERVINGS: 25 MINUTES | 6-8 SERVINGS: 50 MINUTES

INGREDIENTS

2-3 SERVINGS	4-6 SERVINGS	6-8 SERVINGS
1 cup half & half	1 1/2 cups half & half	2 1/4 cups half & half
2 cups black coffee	3 cups black coffee	4 1/2 cups black coffee
1 teaspoon vanilla extract	2 teaspoons vanilla extract	1 tablespoon vanilla extract
1/3 cup granulated sugar	1/2 cup granulated sugar	3/4 cup granulated sugar

TOPPINGS (optional)

Whipped cream
 Chocolate sauce
 Caramel sauce

DIRECTIONS

Prior to starting recipe, refer to pages 6 and 7 for assembly and unit interaction information.

1. In a pitcher or large bowl, whisk together all ingredients until combined and sugar is fully dissolved.
2. Pour mixture into the vessel.
3. Select **FRAPPÉ**. Preset will start at the default/optimal temperature for ideal texture. If desired, adjust temperature.
4. Once frozen drink reaches optimal temperature, unit will beep. Serve immediately, topped with whipped cream and chocolate and/or caramel sauce as desired.

TIP: When using the Milkshake or Frappé preset, dispense contents within 30 minutes of the preset ending to avoid a foamy output.

TEMPERATURE PROGRESS: Temperature Control LEDs pulse showing progress to reach your selected temperature. Unit will beep and LEDs will remain solid once frozen drink reaches temperature.



MAKE IT DAIRY FREE:

Swap out dairy ingredients for dairy-free alternatives if desired.

NOTE: For easier cleaning, **DO NOT** turn off preset until all frozen drink has been dispensed.

FROSÉ

SPIKED
SLUSH

PREP: 5 MINUTES
TOTAL TIME: 2-3 SERVINGS: 30 MINUTES | 4-6 SERVINGS: 40 MINUTES | 6-8 SERVINGS: 50 MINUTES

INGREDIENTS

2-3 SERVINGS	4-6 SERVINGS	6-8 SERVINGS
2 cups + 2 tablespoons rosé wine	3 1/4 cups rosé wine	4 1/3 cups rosé wine
1 cup + 2 tablespoons white cranberry- strawberry juice	2 1/4 cups white cranberry- strawberry juice	3 cups white cranberry- strawberry juice
1/4 cup simple syrup	1/2 cup simple syrup	2/3 cup simple syrup

GARNISH (optional)

Strawberries

DIRECTIONS

Prior to starting recipe, refer to pages 6 and 7 for assembly and unit interaction information.

1. In a pitcher or large bowl, whisk together all ingredients until combined.
2. Pour mixture into the vessel.
3. Select **SPIKED SLUSH**. Preset will start at the default/ideal temperature for ideal texture. Adjust temperature control to illuminate 8 bars.
4. Once frozen drink reaches optimal temperature, unit will beep. Garnish and serve immediately.

TIP: For best results, chill liquid before adding to the unit.

NOTE: For easier cleaning, **DO NOT** turn off preset until all frozen drink has been dispensed.

TEMPERATURE PROGRESS: Temperature Control LEDs pulse showing progress to reach your selected temperature. Unit will beep and LEDs will remain solid once frozen drink reaches temperature.

RED SANGRIA

SPIKED
SLUSH

PREP: 5 MINUTES
TOTAL TIME: 2-3 SERVINGS: 35 MINUTES | 4-6 SERVINGS: 40 MINUTES | 6-8 SERVINGS: 45 MINUTES

INGREDIENTS

2-3 SERVINGS	4-6 SERVINGS	6-8 SERVINGS
1 1/4 cups red wine	2 1/2 cups red wine	3 1/4 cups red wine
2 1/2 tablespoons orange liqueur or brandy	1/3 cup orange liqueur or brandy	1/2 cup orange liqueur or brandy
1 1/2 cups orange juice	3 cups orange juice	3 3/4 cups orange juice
1 1/2 tablespoons light brown sugar	3 tablespoons light brown sugar	1/4 cup light brown sugar

GARNISH (optional)

Orange slices

DIRECTIONS

Prior to starting recipe, refer to pages 6 and 7 for assembly and unit interaction information.

1. In a pitcher or large bowl, whisk together all ingredients until combined and sugar is fully dissolved.
2. Pour mixture into the vessel.
3. Select **SPIKED SLUSH**. Preset will start at the default/optimal temperature for ideal texture. If desired, adjust temperature.
4. Once frozen drink reaches optimal temperature, unit will beep. Garnish and serve immediately.

TIP: For best results, chill liquid before adding to the unit.

NOTE: For easier cleaning, **DO NOT** turn off preset until all frozen drink has been dispensed.

TEMPERATURE PROGRESS: Temperature Control LEDs pulse showing progress to reach your selected temperature. Unit will beep and LEDs will remain solid once frozen drink reaches temperature.

CREATE YOUR OWN SLUSH

with syrup, extracts, and flavored drink powders

TOTAL TIME: 2-3 SERVINGS: 15 MINUTES | 4-6 SERVINGS: 30 MINUTES | 6-8 SERVINGS: 45 MINUTES

	2-3 SERVINGS	4-6 SERVINGS	6-8 SERVINGS	MIX	POUR	DISPENSE
SYRUPS	1/2 cup flavored syrup 2 1/2 cups water	1 cup flavored syrup 5 cups water	1 1/3 cups flavored syrup 6 1/2 cups water	<p>In a pitcher or large bowl, combine flavoring of choice with water and mix until ingredients are completely dissolved.</p>	<p>Pour mixture into vessel, then select SLUSH. The preset will start at the default/optimal level. If desired, adjust the temperature level for your desired frozen drink texture.</p>	<p>For best results, chill serving glasses before dispensing and enjoying your creation.</p>
	<p>FLAVOR INSPIRATION Blue raspberry, grape, grapefruit, green apple, lime, mango, orange, pineapple, pomegranate, watermelon</p>					
EXTRACTS	1/2 tablespoon extract 1/4 cup sugar 4 drops food coloring, optional 3 cups water	1 tablespoon extract 1/2 cup sugar 6 drops food coloring, optional 6 cups water	2 tablespoons extract 2/3 cup sugar 7 drops food coloring, optional 8 cups water			
	<p>FLAVOR INSPIRATION Coconut, lemon, lime, orange, root beer, strawberry</p>					
FLAVORED DRINK POWDERS	1/4 cup drink powder 3 cups water	1/2 cup drink powder 6 cups water	3/4 cup drink powder 7 3/4 cups water			
	<p>FLAVOR INSPIRATION Blue raspberry, cherry, fruit punch, grape, iced tea, lemonade, lemon-lime electrolytes</p>					

CREATE YOUR OWN SLUSH

with prepared drinks

TOTAL TIME: 2-3 SERVINGS: 15 MINUTES | 4-6 SERVINGS: 30 MINUTES | 6-8 SERVINGS: 45 MINUTES

PICK A RECIPE	CHOOSE FLAVOR 1 AND CORRESPONDING SERVING AMOUNT TO VESSEL				CHOOSE FLAVOR 2 AND CORRESPONDING SERVING AMOUNT TO VESSEL															
FLAVOR COMBO	FLAVOR 1	2-3 SERVINGS	4-6 SERVINGS	6-8 SERVINGS	FLAVOR 2	2-3 SERVINGS	4-6 SERVINGS	6-8 SERVINGS												
PEACH ICED TEA	Sweetened iced tea	2 cups	4 cups	5 cups	Peach nectar	1 cup	2 cups	2 ³ / ₄ cups												
POMEGRANATE ICED TEA					Pomegranate juice															
PINEAPPLE ICED TEA					Pineapple juice															
PASSION FRUIT ICED TEA					Passion fruit nectar															
MANGO ICED TEA					Mango nectar															
CRANBERRY-STRAWBERRY LEMONADE	Sweetened lemonade				2 cups				4 cups	5 cups	Cranberry-strawberry juice	1 cup	2 cups	2 ³ / ₄ cups						
MANGO LEMONADE											Mango nectar									
PEACH LEMONADE											Peach nectar									
HALF & HALF											Sweetened ice tea									
ORANGE LEMONADE											Orange juice									
CHERRY LIMEADE	Limeade	2 cups	4 cups	5 cups		Cherry juice	1 cup	2 cups			2 ³ / ₄ cups									
POMEGRANATE LIMEADE						Pomegranate juice														
PARTY PUNCH	Lemon-lime soda					2 cups									4 cups	5 cups	Fruit punch	1 cup	2 cups	2 ³ / ₄ cups
CHERRY COLA	Cola																Cherry juice			
CRANBERRY ORANGE	Orange juice																Cranberry juice			

Select SLUSH. The preset will start at the default level. Adjust temperature control to illuminate 2 bars.

Select SLUSH. The preset will start at the default level.

Select FROZEN JUICE. The preset will start at the default level.

CREATE YOUR OWN MILKSHAKE & FRAPPÉ

with syrup, milk powder, flavored milk, and store-bought coffee drinks

TOTAL TIME: 2-3 SERVINGS: 15 MINUTES | 4-6 SERVINGS: 25 MINUTES | 6-8 SERVINGS: 35 MINUTES

	2-3 SERVINGS	4-6 SERVINGS	6-8 SERVINGS	MIX	POUR	DISPENSE
FLAVORED SYRUPS/SAUCES	2 cups whole milk 1 cup heavy cream 1 teaspoon vanilla extract 2 tablespoons granulated sugar 1/4 cup flavored syrup/sauce	4 cups whole milk 2 cups heavy cream 2 teaspoons vanilla extract 1/4 cup granulated sugar 1/2 cup flavored syrup/sauce	4 1/3 cups whole milk 2 1/3 cups heavy cream 1 tablespoon vanilla extract 1/3 cup granulated sugar 2/3 cup flavored syrup/sauce	In a pitcher or large bowl, whisk together all ingredients until dissolved and combined.	Pour mixture into unit, select MILKSHAKE, and adjust temperature as desired.	Dispense and enjoy.
	FLAVOR INSPIRATION Strawberry, caramel, chocolate, coffee					
FLAVORED MILK POWDERS	2/3 cup drink powder 2 1/2 cups whole milk 1/2 cup heavy cream	1 1/4 cup drink powder 5 cups whole milk 1 cup heavy cream	1 2/3 cups drink powder 6 2/3 cups whole milk 1 1/3 cups heavy cream			
	FLAVOR INSPIRATION Chocolate milk, strawberry milk, hot cocoa					
FLAVORED MILKS	2 1/2 cups flavored milk 1/2 cup heavy cream 1/2 cup granulated sugar	5 cups flavored milk 1 cup heavy cream 1 cup granulated sugar	5 3/4 cups flavored milk 1 cup + 2 tablespoons heavy cream 1 1/4 cups granulated sugar			
	FLAVOR INSPIRATION Chocolate milk, strawberry milk, coffee milk					
STORE-BOUGHT COFFEE DRINKS	2 3/4 cups store-bought coffee drink 2 tablespoons heavy cream	5 3/4 cups store-bought coffee drink 1/4 cup heavy cream	7 2/3 cups store-bought coffee drink 1/3 cup heavy cream		Pour mixture into unit, select FRAPPÉ, and adjust temperature as desired.	
	FLAVOR INSPIRATION Store-bought bottled frappés, mochas, sweetened iced coffee drinks, cappuccinos, lattes, macchiatos, matcha lattes					

CREATE YOUR OWN SPIKED SLUSH

with juice or soda and alcohol

TOTAL TIME: 2-3 SERVINGS: 30 MINUTES | 4-6 SERVINGS: 40 MINUTES | 6-8 SERVINGS: 50 MINUTES

PICK A RECIPE	ADD JUICE ACCORDING TO SERVING AMOUNT TO VESSEL			ADD ALCOHOL ACCORDING TO SERVING AMOUNT TO VESSEL			Select SPIKED SLUSH. The preset will start at the default/optimal level.		
JUICE & ALCOHOL COMBO	JUICE	2-3 SERVINGS	4-6 SERVINGS	6-8 SERVINGS	ALCOHOL	2-3 SERVINGS		4-6 SERVINGS	6-8 SERVINGS
CAPE CODDER	Cranberry juice	2 1/2 cups	5 cups	6 2/3 cups	Vodka	1/2 cup		1 cup	1 1/4 cups
BELLINI	Peach nectar				Champagne				
SCREWDRIVER	Orange juice				Vodka				
GREYHOUND	Grapefruit juice				Gin				
BLOODY MARY	Tomato juice				Vodka				
CINNAMON WHISKEY CIDER	Apple cider				Cinnamon whiskey				

PICK A RECIPE	ADD SODA ACCORDING TO SERVING AMOUNT TO VESSEL			ADD ALCOHOL ACCORDING TO SERVING AMOUNT TO VESSEL			Select SPIKED SLUSH. The preset will start at the default/optimal level.		
SODA & ALCOHOL COMBO	SODA	2-3 SERVINGS	4-6 SERVINGS	6-8 SERVINGS	ALCOHOL	2-3 SERVINGS		4-6 SERVINGS	6-8 SERVINGS
WHISKEY COLA	Cola	2 1/2 cups	5 cups	6 2/3 cups	Whiskey	1/2 cup		1 cup	1 1/4 cups
RUM & COLA	Regular or diet cola				Rum				
PALOMA	Grapefruit soda				Tequila				
WHISKEY & GINGER	Ginger ale				Whiskey				
SPIKED LEMONADE	Lemonade				Vodka				
DARK & STORMY	Ginger beer				Rum				

NINJA
SLUSHiTM
PROFESSIONAL FROZEN DRINK MAKER

© 2024 SharkNinja Operating LLC.
NINJA SLUSHI is a trademark of SharkNinja Operating LLC.
FS301Series_IG_10Recipe_MP_Mv27