


LOAD IT UP

DO NOT blend without ingredients or without lid.
DO NOT go past MAX FILL line when loading vessel.



PREP TIPS: For best results, cut ingredients in 1–2-inch pieces.

5 **Finish** off with ice or frozen ingredients.

4 Then add dry or stick ingredients like seeds, **protein powders**, and nut butters.

3 Then add up to 1 cup of leafy greens.

2 Next add fresh fruits. (for best results, cut in 1–2-inch pieces).

1 **Start** by adding liquid up to the **MIN LIQUID** line.



For how-to videos and getting started, scan the QR code.

CARROT APPLE KALE WAKE-UP

PREP: 5 MINUTES
TOTAL TIME: 6 MINUTES
MAKES: 1–2 SERVINGS

INGREDIENTS

¾ cup carrot juice
1 cup packed chopped kale, stems removed
¼ cup green apple peeled, cored, cut into ½-inch chunks
½ cup frozen pineapple chunks

DIRECTIONS

- 1 Install the vessel onto the motor base, twisting clockwise until the vessel clicks onto the motor base.
- 2 Turn the unit ON using the power button and ensure the **⏻** is **GREEN**, indicating the battery is full.
- 3 Remove the lid and add ingredients to the blending vessel in the order listed. Secure the lid to the vessel.
- 4 Select **BLEND**.
- 5 After blending, if smoother consistency is desired, press **BLEND** again.
- 6 When blending is complete, power motor base off, remove the vessel from the motor base, and enjoy through the sip lid.

FROZEN MOCHA COLD BREW

PREP: 3 MINUTES
TOTAL TIME: 4 MINUTES
MAKES: 1–2 SERVINGS

INGREDIENTS

1 cup cold brew coffee concentrate
½ cup whole milk
¼ cup chocolate syrup
¾ cup ice

DIRECTIONS

- 1 Install the vessel onto the motor base, twisting clockwise until the vessel clicks onto the motor base.
- 2 Turn the unit ON using the power button and ensure the **⏻** is **GREEN**, indicating the battery is full.
- 3 Remove the lid and add ingredients to the blending vessel in the order listed. Secure the lid to the vessel.
- 4 Select **CRUSH**.
- 5 When blending is complete, power motor base off, remove the vessel from the motor base, and enjoy through the sip lid.

NOTE:

- Milk may expand during processing. If removing lid before drinking, do so carefully to avoid spilling.
- Unintentional blending can occur when the lid is removed. Turn the motor base off using the **⏻** button when not in use.

MIXED BERRY VANILLA PROTEIN SMOOTHIE

PREP: 3 MINUTES
TOTAL TIME: 4 MINUTES
MAKES: 1–2 SERVINGS

INGREDIENTS

1 ¼ cups oat milk
1 scoop (1 ounce) vanilla whey protein powder
1 cup mixed frozen berries

DIRECTIONS

- 1 Install the vessel onto the motor base, twisting clockwise until the vessel clicks onto the motor base.
- 2 Turn the unit ON using the power button and ensure the **⏻** is **GREEN**, indicating the battery is full.
- 3 Remove the lid and add ingredients to the blending vessel in the order listed. Secure the lid to the vessel.
- 4 Select **SMOOTHIE**.
- 5 When blending is complete, power motor base off, remove the vessel from the motor base, and enjoy through the sip lid.

MANGO MARGARITA

PREP: 4 MINUTES
TOTAL TIME: 5 MINUTES
MAKES: 2 SERVINGS

INGREDIENTS

⅓ cup tequila
3 tablespoons triple sec
½ cup frozen lime cocktail mixer
1 cup frozen mango chunks
⅓ cup ice

DIRECTIONS

- 1 Install the vessel onto the motor base, twisting clockwise until the vessel clicks onto the motor base.
- 2 Turn the unit ON using the power button and ensure the **⏻** is **GREEN**, indicating the battery is full.
- 3 Remove the lid and add ingredients to the blending vessel in the order listed. Secure the lid to the vessel.
- 4 Select **CRUSH**.
- 5 When blending is complete, power motor base off, remove the vessel from the motor base, and enjoy through the sip lid.

TIP: If a creamier output is desired, remove vessel from motor base after processing, shake, then reinstall vessel and press **BLEND**. Process until complete.

NOTE: Unintentional blending can occur when the lid is removed. Turn the motor base off using the **⏻** button when not in use.

APPLE CINNAMON OAT BREAKFAST SMOOTHIE

PREP: 5 MINUTES
TOTAL TIME: 6 MINUTES
MAKES: 1–2 SERVINGS

INGREDIENTS

1 cup whole milk
2 tablespoons maple syrup
½ cup green apple, peeled, cored, cut into ½-inch chunks
½ cup frozen banana slices
½ cup whole milk vanilla yogurt
1 teaspoon ground cinnamon
3 tablespoons quick oats
Pinch kosher salt

DIRECTIONS

- 1 Install the vessel onto the motor base, twisting clockwise until the vessel clicks onto the motor base.
- 2 Turn the unit ON using the power button and ensure the **⏻** is **GREEN**, indicating the battery is full.
- 3 Remove the lid and add ingredients to the blending vessel in the order listed. Secure the lid to the vessel.
- 4 Select **SMOOTHIE**.
- 5 When blending is complete, power motor base off, remove the vessel from the motor base, and enjoy through the sip lid.

NOTE: Unintentional blending can occur when the lid is removed. Turn the motor base off using the **⏻** button when not in use.


Please make sure to read the enclosed Ninja® Owner's Guide prior to using your unit.

NINJA BLAST™ MAX

22
oz



QUICK ASSEMBLY



For best results, ensure the blender is fully charged before use.

Clean before first use.

NOTE: Accessories and color vary by model.

▲WARNING: Handle the blade assembly with care when washing, as the blades are sharp. Contact with the blades' edges can result in laceration.

CONTROL PANEL

LED Indicators:

Displayed through power button icon and blending program LEDs.



Charging:

- Use the provided charging cable to charge the unit.
- Charge the unit fully before first use.
- A full charge should take approximately 3 hours.



Flashing Green
Plugged In
Charging



Solid Green
Fully Charged



Solid Orange
Medium Charge



Solid Red
Low battery



Flashing Red
No Battery

Ready to Blend

Blending Programs Solid White
Power LED will illuminate with battery life color.



Blocked Blades Error

Selected Blending Program Flashes Purple
Ingredients are stuck in the blades. Add more liquid or shake the vessel to dislodge the blocked ingredients from the blades.



Vessel Improperly Installed Error

Blending Programs Flash White
Vessel is not properly installed onto motor base. Re-install vessel. Vessel will "click" when properly installed onto motor base.



Motor Overheating Protection Error

Blending Program Solid Orange
Motor base is overheating. Let sit at room temperature to cool down for 60 minutes.



NOTE: Unit will not charge if overheating error is present.

BLENDING INSTRUCTIONS

Before blending, ensure your blender is fully charged.

Check the battery LED color before blending.

(**Solid Green:** fully charged,
Solid Red: low battery,
Flashing Red: no battery)

- 1 Install the vessel onto the motor base, twisting clockwise until the vessel clicks onto the motor base.
- 2 Turn the unit ON using the power button and ensure the power icon is **GREEN**, indicating the battery is full.

Refer to LED guide on side of motor base for more battery information.



- 3 Remove the lid before loading ingredients.
- 4 Add your ingredients, starting with liquid ingredients, then adding softer ingredients, and finishing with tougher ingredients (frozen fruit and ice).
- 5 Secure the lid to the vessel.
- 6 Select your blending mode:
Blend: (30-second manual) for protein shakes
Crush: for frozen drinks with ice
Smoothie: for fresh or frozen fruit smoothies
- 7 When blending is complete, remove the vessel from the motor base and enjoy through the sip lid.

CLEANING INSTRUCTIONS

DO NOT expose the motor base to liquid during the cleaning process.

Remove vessel from motor base before cleaning vessel.

QUICK CLEAN

- 1 Remove vessel from motor base and remove lid from vessel. Add warm water to the 6 oz. line then add 1 small drop of dish soap.
- 2 Secure the lid onto the vessel, attach the vessel onto the motor base, and press BLEND.
- 3 After blend is complete, remove vessel from motor base, empty contents, and rinse vessel and lid with warm water.
- 4 If needed, wipe motor base with a damp cloth.



HAND-WASH

- 1 Remove the vessel from the motor base and wash the lid and vessel with warm soapy water.
- 2 Use a dishwashing utensil to clean the CrushBlade™ Assembly inside the vessel. Exercise care when cleaning the CrushBlade™ Assembly as the blades are sharp.
- 3 Empty contents and rinse vessel and lid with warm water.

DISHWASHER CLEANING

- 1 Vessel and sip lid are top-rack dishwasher safe. **DO NOT** use a heated dry cycle.



NINJA BLAST™ MAX



For additional recipes and information on Ninja Blast™ Max, scan the QR code.

© 2024 SharkNinja Operating LLC.
AUTO-IQ and NINJA are registered trademarks of SharkNinja Operating LLC.

CRUSHBLADE and NINJA BLAST are trademarks of SharkNinja Operating LLC.

BC250Series_QSG_IG_MP_Mv7